



Chemical resistance of plastics



Legend

Two values are given per substance. left number = value at +20°C / right number = value at +50°C

0	no data available
1	resistant
2	practically resistant
3	partially resistant
4	not resistant
K	no general information available
L	danger of pitting or stress-cracking corrosion
()	estimated value

Hazard notes

E	explosive
O	oxidizing
F	highly flammable
F+	extremely flammable
T	toxic
T+	very toxic
C	corrosive
Xn	harmful
Xi	irritant
N	dangerous for the environment

Description of the materials

Thermoplastics

HDPE	Polyethylene (high density)
LDPE	Polyethylene (low density)
PA	Polyamide (Nylon)
PC	Polycarbonate
PETG	Polyethylene terephthalate glycol (PET copolymer)
PMP	Polymethylpentene (TPX)
POM	Polyoxymethylene, polyacetal
PP	Polypropylene
PS	Polystyrene
PSU	Polysulfone
PVC	Polyvinyl chloride
SAN	Styrene-acrylnitrile

Fluoroplastics

E-CTFE	Ethylene-chlorotrifluoroethylene (Halar)
ETFE	Ethylene-tetrafluoroethylene
FEP	Tetrafluoroethylene-perfluoropropylene (Teflon, FEP)
PTFE	Polytetrafluoroethylene (Teflon)
PVDF	Polyvinylidene fluoride

Elastomers

EPDM	Ethylene-propylene-diene rubber
FPM/FKM	Fluorinated rubber (Viton)
NBR	Acryl-nitrile-butadiene rubber
SI	Silicone rubber

Metals

Al	Aluminium
V2A	Stainless steel 1.4301 (AISI 304)
V4A	Stainless steel 1.4401 (AISI 316)
Hastelloy C	Nickel-chromium-molybdenum alloy

Important information

The table „Chemical resistance of plastics“ was kindly provided by the company Bürkle GmbH to the Kendrion Kuhnke Automation GmbH and was integrated into the Kendrion layout. This table is based on information provided by various raw material manufacturers. These values are based solely on laboratory tests with raw materials. Plastic components produced from these raw materials are frequently subject to influences that cannot be recognized in laboratory tests (temperature, pressure, material stress, effects of chemicals, construction features, etc.). For this reason the values given are only to be regarded as being guidelines. In critical cases it is essential that a test is carried out first. No legal claims can be derived from this information; nor do Bürkle GmbH or we accept any liability for it. A knowledge of the chemical and mechanical resistance alone is not sufficient for the evaluation of the usability of a product. For example, the regulations concerning flammable liquids (explosion prevention) must also be taken into consideration.

Copyright

This table has been published and updated by Bürkle GmbH, D-79415 Bad Bellingen as a work of reference. This Copyright clause must not be removed. The table may be freely passed on and copied, provided that the information about the publisher is retained.

Herausgeber

Bürkle GmbH, Rheinauen 5, D-79415 Bad Bellingen, Phone +49 (7635) 82795-0, Fax +49 (7635) 82795-31, info@buerkle.de, www.buerkle.de

Version 3.2 (26.01.2015)

CHEMICALS	thermoplastics																												fluoroplastics				elastomers				metals				COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE /ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A												
Acetaldehyde	C ₂ H ₄ O	000075-07-0	40 %	F+, Xn	X	3/3	2/4	2/0	4/4	(4)	2/4	2/0	3/4	4/4	4/4	4/4	0/0	4/4	2/3	(1)	1/1	4/4	3/0	4/4	4/4	0/0	(1)	(1)	(1)	3/4	Acetic aldehyde; Ethanal; Ethyl aldehyde										
Acetaldehyde	C ₂ H ₄ O	000075-07-0	techn. pure	F+, Xn	X	3/3	2/4	2/0	4/4	(4)	2/4	2/0	3/4	4/4	4/4	4/4	0/0	4/4	2/3	(1)	1/1	4/4	3/0	4/4	4/4	0/0	(1)	(1)	(1)	1/1											
Acetamide	C ₂ H ₅ NO	000060-35-5	saturated	Xn		1/1	1/1	1/0	4/4	0/0	1/1	1/0	1/1	1/1	4/4	4/4	0/0	1/1	1/1	1/1	1/1	1/0	4/4	1/0	0/0	(1)	(1)	(1)	1/1												
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	50 %	C		1/1	1/1	4/4	1/2	0/0	1/1	3/4	1/1	2/2	1/2	0/0	0/0	1/2	1/1	1/1	1/1	4/4	4/4	0/0	1/3	1/1	1/1	1/1	1/1												
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	100 %	C+	X	0/0	0/0	4/4	4/4	4/4	(3)	4/4	1/3	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	4/4	4/4	4/4	0/0	1/3	1/2	1/2	1/1											
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	90 %	C+	X	1/1	1/2	4/4	4/4	4/4	1/3	4/4	1/2	4/4	3/4	1/2	4/4	4/4	1/1	1/1	1/1	1/1	4/4	4/4	4/4	0/0	1/3	1/2	1/2	1/1											
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	10 %	Xi		1/1	1/1	4/4	1/2	1/1	3/0	1/4	1/1	1/0	1/3	1/0	1/3	1/1	1/1	1/1	1/1	(2)	(3)	3/3	0/0	1/3	1/1	1/1	1/1	1/1											
Acetic acid	C ₂ H ₄ O ₂	000064-19-7	5 %	Xi		1/1	1/3	4/4	1/2	1/1	1/1	1/3	1/1	1/1	1/1	1/1	3/0	1/1	1/1	1/1	1/1	1/0	3/3	3/3	0/0	1/3	1/2	1/1	1/1	1/1											
Acetic acid chloride	-> see: Acetyl chloride																																								
Acetic acid sodium salt	-> see: Sodium acetate																																								
Acetic aldehyde	-> see: Acetaldehyde																																								
Acetic anhydride	C ₄ H ₆ O ₃	000108-24-7	techn. pure	C	X	4/4	3/3	3/3	4/4	0/0	4/4	(2)	1/3	4/4	4/4	4/4	0/0	0/0	1/0	1/1	4/4	3/0	4/4	4/4	0/0	(2)	1/1	1/1	1/1	1/1											
Acetic chloride	-> see: Acetyl chloride																																								
Acetone	C ₃ H ₆ O	000067-64-1		F, Xi	X	1/1	3/3	1/0	4/4	4/4	2/3	1/3	1/3	4/4	4/4	4/4	0/0	4/4	2/3	(1)	1/1	3/4	1/0	4/4	4/4	0/0	1/1	1/1	1/1	1/1	Propanone, 2-; Dimethyl ketone; Methyl ketone										
Acetonitrile	C ₂ H ₃ N	000075-05-8		F, T	X	1/1	1/1	1/0	4/4	(4)	3/4	(3)	3/4	4/4	4/4	4/4	0/0	0/0	1/1	(1)	(1)	1/1	(3)	(3)	4/4	0/0	(1)	(1)	0/0		Methyl cyanide; Cyanomethane; Ethanenitrile										
Acetonyl chloride	-> see: Chloroacetone																																								
Acetophenone	C ₈ H ₈ O	000098-86-2		Xn		0/0	1/0	1/0	(4)	(4)	(4)	1/0	1/3	0/4	0/0	4/4	4/4	0/4	1/1	0/0	1/1	1/3	1/0	4/4	4/4	0/0	1/1	(1)	(1)	0/0	Phenylethanone, 1-; Phenyl methyl ketone; Acetylbenzene										
Acetyl chloride	C ₂ H ₃ ClO	000075-36-5	100 %	F, C	X	0/0	0/0	4/4	4/4	(4)	(4)	4/4	3/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	1/1	4/4	1/0	4/4	0/0	4/4	1/2L	1/1L	0/0	Acetic chloride; Ethanoyl chloride; Acetic acid chloride										
Acetylene	C ₂ H ₂	000074-86-2	100 %	F+	X	1/0	1/0	1/0	1/0	1/1	0/0	1/0	1/0	0/0	0/0	2/0	4/4	3/0	(1)	1/1	1/0	(1)	1/0	1/0	1/0	0/0	(1)	(1)	(1)	1/1	Ethine; Ethyne										
Acetyloxybenzoic acid, 2-	-> see: Acetylsalicylic acid																																								
Acetylsalicylic acid	C ₉ H ₈ O ₄	000050-78-2	100 %	Xn		0/0	0/0	1/0	0/0	(2)	0/0	(3)	1/2	1/0	0/0	0/0	0/0	1/1	1/1	1/1	1/2	(2)	(3)	0/0	0/0	1/0	1/0	1/0	1/0	1/0	Acetyloxybenzoic acid, 2-;										
Acrylonitrile	C ₃ H ₃ N	000107-13-1		F, T	X	1/1	1/3	1/0	4/4	(4)	3/4	(3)	3/4	4/4	4/4	4/4	0/0	1/2	1/1	1/0	3/3	4/4	4/4	4/4	0/0	1/0	1/0	1/0	1/1	1/1	Cyanoethylene; Propenenitrile, 2-; Vinyl cyanide										
Adipic acid	C ₆ H ₁₀ O ₄	000124-04-9	saturated	Xi		1/1	1/2	0/0	1/1	(2)	1/1	1/3	1/1	1/1	2/2	1/3	1/3	0/0	1/1	1/1	1/1	1/0	1/0	1/0	1/1	0/0	1/0	(2)	(2)	1/1	Hexanedioic acid; Butanedicarboxylic acid, 1,4-										
Alanine, L-	C ₃ H ₇ NO ₂	000056-41-7		—		1/1	1/1	1/1	4/4	(2)	1/1	(1)	1/1	1/1	4/4	4/4	0/0	0/0	1/1	1/1	1/1	(1)	1/0	(1)	(1)	0/0	(2)	(2)	(2)		Aminopropanoic acid, L-2; aminopropanoic acid, alpha-										
Allspice	—	—	ground	?		0/0	0/0	(2)	4/4	0/0	(2)	(2)	4/4	0/0	0/0	0/0	3/3	0/0	(1)	(1)	(1)	(2)	(2)	0/0	(1)	(1)	(1)														
Allyl acetate	C ₅ H ₈ O ₂	000591-87-7	100 %	F, T	X	0/0	1/3	4/4	4/4	(4)	(4)	(2)	1/3	4/4	0/0	0/0	4/4	0/0	0/0	(1)	1/1	(2)	(3)	4/4	4/4	0/0	(1)	(1)	(1)												
Allyl alcohol	C ₃ H ₆ O	000107-18-6	96 %	F, T	X	1/3	3/3	3/0	3/3	1/0	1/2	(2)	2/2	2/4	2/3	2/3	4/4	4/4	1/1	1/1	(2)	1/0	4/4	3/0	0/0	1/1	1/1	1/1	1/1	1/1	Vinyl carbinol; Propenyl alcohol										
Allyl chloride	C ₃ H ₅ Cl	000107-05-1	100 %	F, T+	X	(3)	3/4	0/0	(4)	(4)	(4)	0/0	4/0	4/4	4/4	4/4	0/0	0/0	(1)	(2)	1/1	4/4	(3)	4/4	0/0	1/0	(1L)	(1L)	0/0	Chloro-1-propene, 3-; Chloropropylene, 3-											
Allyl mustard oil	C ₈ H ₉ NS	000057-06-7		T	X	0/0	0/0	0/0	(4)	(3)	(4)	(2)	(2)	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(3)	(3)	(4)	0/0	(1)	(1)	(1)		oleum sinapis											
Almond oil, sweet	—	008007-69-0		—		0/0	0/0	(2)	(1)	1/0	0/0	(2)	(2)	3/4	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	(1)	(2)	0/0	(1)	1/1	1/1												
Alumina acid	C ₂ H ₂ AlO ₅ x H ₂ O	000142-03-0	saturated	Xi		1/1	1/0	(2)	(2)	(2)	0/0	1/0	1/0	1/0	0/0	1/0	1/0	1/1	1/1	1/1	(1)	1/0	4/4	3/3	0/0	(1)	1/1	1/1													
Aluminium fluoride	AlF ₃	007789-18-1	aqueous	Xi		1/1	1/1	(3)	(2)	(2)	1/1	3/4	1/1	0/0	0/0	1/3	1/3	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	0/0	0/0	0/0											
Aluminum ammonium sulfate dodecahydrate	(NH ₄) ₂ Al(SO ₄) ₂	007784-26-1	saturated	Xi		1/1	1/1	3/4	(2)	(2)	0/0	3/4	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	(2)	1/1	0/0	1/0	1/2	1/3	0/0											
Aluminum chloride	AlCl ₃	007784-13-6	10 %	?		1/1	1/2	1/0	1/0	(2)	1/1	3/4	1/1	0/0	1/1	0/0	1/1	0/0	1/1	2/2	1/1	1/1	1/0	1/0	1/0	0/0	4/4	4/4	3/4	1/1											
Aluminum chloride	AlCl ₃	007784-13-6	solid	C		1/1	1/1	3/4	(3)	0/0	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	(3)	(3)	(3)	0/0	4/4	4/4	3/4	1/1											
Aluminum chloride	AlCl ₃	007784-13-6	saturated	C		1/1	1/1	3/4	(2)	0/0	0/0	4/4	1/1	0/0	0/0	1/1	0/0	1/1	0/0	1/1	(1)	1/1	(2)	1/0	1/1	0/0	4/4	4/4	3/4	1/1											
Aluminum hydroxide	Al(OH) ₃	021645-51-2		Xi		1/1	1/2	1/1	1/1	1/1	1/2	1/1	1/2	2/2	2/2	1/2	1/1	1/1	1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	small solubility - no chemical effect expected										
Aluminum nitrate	Al(NO ₃) ₃	013473-90-0	aqueous	(O)		1/1	1/0	1/4	1/0	(2)	1/0	3/4	1/1	1/0	1/0	1/0	1/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	4/4	1/0	1/0	1/1											
Aluminum oxide, alpha-	Al ₂ O ₃	001344-28-1	solid	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	small solubility - no chemical effect expected										
Aluminum potassium sulfate	KAl(SO ₄) ₂ x 12H ₂ O	010043-67-1	diluted	Xi		1/1	1/1	1/0	1/0	(2)	0/0	3/4	1/1	1/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/1	1/0	3/3	0/0	1/0	1/1	1/1	1/1	1/1											
Aluminum potassium sulfate	KAl(SO ₄) ₂ x 12H ₂ O	010043-67-1	saturated	Xi		1/1	1/1	1/0	1/0	(2)	0/0	3/4	1/1	1/0	1/0	1/3	1/3	0/0	1/1	1/1	1/1	1/1	1/0	3/3	0/0	1/0	(1)	(1)	0/0												
Aluminum sodium sulfate	NaAl(SO ₄) ₂	010102-71-3		?		1/1	1/1	(3)	(2)	(1)	0/0	(3)	1/1	0/																											

CHEMICALS	thermoplastics																												fluoroplastics			elastomers			metals			COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE /ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C								
Ammonium chloride	(NH ₄)Cl	012125-02-9	solid	Xn		1/1	1/1	1/0	1/0	(2)	0/0	2/3	1/1	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/1	0/0	3/4	1/3L	1/2L	1/1	sal ammoniac							
Ammonium chloride	(NH ₄)Cl	012125-02-9	aqueous	Xn		1/1	1/1	1/0	1/0	(2)	1/1	2/3	1/1	1/1	1/0	1/3	1/3	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	3/4	1/3L	1/2L	1/1	sal ammoniac								
Ammonium difluoride	F ₂ H ₂ N	001341-49-7	50 %	T, C		1/1	1/1	2/0	(4)	0/0	0/0	(4)	1/1	0/0	0/0	1/3	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	2/3	0/0	(3)	1/0	1/0									
Ammonium ferric sulfate	(NH ₄)Fe(SO ₄) ₂	007783-83-7	saturated	Xi		1/1	1/1	1/0	(2)	(2)	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	(2)	(1)	0/0	(4)	0/0	0/0										
Ammonium ferrous sulfate	(NH ₄) ₂ Fe(SO ₄) ₂	007783-85-9		Xi		1/1	1/1	(2)	(2)	(2)	0/0	(3)	1/1	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	4/4	(1)	(1)										
Ammonium fluoride	(NH ₄)F	012125-01-8	saturated	T, C		1/1	1/1	1/0	4/4	(2)	1/0	(2)	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	2/3	1/1	0/0	(4)	(1)	(1)	?								
Ammonium fluoride	(NH ₄)F	012125-01-8	aqueous	T, C		1/1	1/1	1/0	(3)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	2/3	1/1	0/0	(4)	1/3	1/3	1/1									
Ammonium glycolate	C ₂ H ₇ NO ₃	035249-89-9		(Xi)		1/1	1/2	(1)	2/3	(2)	1/2	(2)	1/2	1/1	2/2	1/1	0/0	0/0	1/1	1/1	1/1	(1)	1/0	(3)	(1)	0/0	(2)	(2)	(2)		Acetic acid							
Ammonium heptamolybdate	(NH ₄) ₆ Mo ₇ O ₂₄	012054-85-2		Xi		1/1	1/1	(1)	(2)	(2)	0/0	(1)	1/1	1/1	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	1/0	(3)	(1)	0/0		(1)	(1)	0/0								
Ammonium hydroxide	NH ₃ + H ₂ O	001336-21-6	30 %	C, N		1/1	1/2	(3)	4/4	2/4	1/2	1/2	1/2	2/3	1/2	0/0	0/0	1/1	1/1	(2)	1/0	(3)	2/3	0/0	1/1	1/1	1/1	1/1	1/1									
Ammonium hydroxide	NH ₃ + H ₂ O	001336-21-6	5 %	Xi		1/1	1/1	(2)	3/4	(2)	1/1	1/2	1/1	1/3	2/2	1/1	0/0	0/0	1/1	1/1	1/1	(2)	1/0	(2)	2/3	0/0	1/1	1/1	1/1	1/1								
Ammonium hydroxide	NH ₃ + H ₂ O	001336-21-6		C/Xi, N		1/1	1/1	(3)	4/4	2/4	1/1	1/2	1/1	2/3	2/3	1/2	1/3	2/2	1/1	1/1	1/1	1/3	1/0	(3)	4/4	0/0	1/1	1/1	1/1	1/1								
Ammonium mercaptan	-> see: Ammonium bisulfide																																					
Ammonium nitrate	(NH ₄)NO ₃	006484-52-2	10 %	O		1/3	0/0	1/0	(1)	(2)	0/0	2/4	1/1	1/1	1/0	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/0	2/2	1/1	0/0	1/1	1/1	1/1	1/1	Nitric acid; Ammonium salt							
Ammonium nitrate	(NH ₄)NO ₃	006484-52-2	saturated	O		1/3	1/1	1/0	1/0	(2)	1/1	2/4	1/1	1/0	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/0	2/2	1/1	0/0	(2)	1/1	1/1	1/1								
Ammonium nitrite	(NH ₄)NO ₂	013446-48-5	aqueous	O, Xn		(1)	(1)	(2)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	1/0	0/0	(2)	(1)	(1)										
Ammonium oxalate	C ₂ H ₄ N ₂ O ₄	014258-49-2		Xn		1/1	1/2	(1)	1/1	(2)	1/2	(2)	1/2	1/1	1/1	1/1	0/0	0/0	1/1	1/1	1/1	(1)	1/0	(3)	(1)	0/0	1/1	1/1	1/1	0/0								
Ammonium persulfate	(NH ₄) ₂ S ₂ O ₈	007727-54-0	saturated	O, Xn		0/0	0/0	4/4	(2)	0/0	0/0	(2)	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	4/4	0/0	4/4	(4)	3/4	0/0								
Ammonium persulfate	(NH ₄) ₂ S ₂ O ₈	007727-54-0	aqueous	O, Xn		0/0	0/0	4/4	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	4/4	0/0	4/4	(4)	3/4	0/0									
Ammonium phosphate, Mono-	(NH ₄)H ₂ PO ₄	007722-76-1	each	Xi		1/1	1/1	1/0	(2)	(2)	1/0	(2)	1/1	1/1	1/0	1/1	1/0	0/0	1/1	1/1	1/1	1/1	1/0	3/0	1/1	0/0	4/4	(1)	(1)	1/1								
Ammonium polyphosphate (APP)	(NH ₄ PO ₃) _n	068333-79-9		Xi		1/1	1/1	(1)	(2)	(2)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	1/0	(3)	1/1	0/0	(3)	(1)	(1)									
Ammonium rhodanide	-> see: Ammonium thiocyanate																																					
Ammonium salt	-> see: Ammonium nitrate																																					
Ammonium sulfate	(NH ₄) ₂ SO ₄	007783-20-2	10 %	Xn		1/1	1/1	1/0	1/1	(2)	(1)	1/0	1/1	1/1	1/0	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/0	2/3	1/1	0/0	1/1	1/1	1/1	1/1								
Ammonium sulfate	(NH ₄) ₂ SO ₄	007783-20-2	saturated	Xn		1/1	1/1	1/0	1/1	(2)	1/1	2/0	1/1	1/0	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/0	2/3	1/1	0/0	1/1	1/1	1/2	1/1								
Ammonium sulfide	(NH ₄) ₂ S	012135-76-1	each	T, C	X	1/1	1/1	1/0	4/4	0/0	1/1	(2)	1/1	0/0	0/0	1/3	1/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	1/2	0/0	1/1	(1)	(1)	?	Diammonium sulfide;							
Ammonium sulfide	(NH ₄) ₂ S	012135-76-1	aqueous	T, C	X	1/1	1/1	1/0	(3)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(3)	3/3	0/0	1/1	(1)	(1)	1/1								
Ammonium sulfocyanide	-> see: Ammonium thiocyanate																																					
Ammonium thiocyanate	CH ₄ N ₂ S	001762-95-4		Xn		1/1	1/1	(3)	1/0	(2)	1/1	1/0	1/1	1/3	0/0	1/0	0/0	1/1	1/1	1/1	1/1	(1)	1/0	(3)	1/0	0/0	(2)	(1)	(1)		Ammonium sulfocyanide; Ammonium rhodanide; Thiocyanic acid, Ammonium salt; Ammonium sulfocyanate							
Amomum	—	—		?		0/0	0/0	(2)	(2)	(2)	0/0	(2)	(2)	4/4	0/0	0/0	0/0	1/1	0/0	(1)	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)									
Amyl acetate, normal	C ₇ H ₁₄ O ₂	000628-63-7		—	X	1/2	2/3	2/0	4/4	1/3	2/3	(1)	3/4	4/4	4/4	4/4	4/4	4/4	1/1	1/1	1/1	1/3	3/4	4/4	4/4	0/0	1/1	1/1	1/1	0/0								
Amyl alcohol, n-	-> see: Pentanol, 1-																																					
Amyl chloride	C ₈ H ₁₇ Cl	000543-59-9		F, Xn	X	3/4	4/4	1/0	4/4	0/0	4/4	(2)	4/4	4/4	4/4	4/4	4/4	0/0	1/1	1/1	1/1	1/1	4/4	1/0	4/4	0/0	3/4	3/4L	3/4L	0/0								
Amyl cinnamic aldehyde	C ₁₄ H ₁₆ O	000122-40-7		Xi		0/0	0/0	0/0	(4)	0/0	(4)	(3)	(3)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(4)	(3)	(4)	0/0	(1)	(1)	(1)		odoriferous substance							
Aniline	C ₆ H ₇ N	000062-53-3		T		1/2	1/3	3/4	4/4	0/0	2/3	1/3	2/3	4/4	4/4	4/4	0/4	2/4	1/1	1/1	1/4	4/4	2/4	4/4	0/0	1/0	1/0	1/0	1/0	1/1								
Aniline hydrochloride	C ₆ H ₅ ClN	000142-04-1	saturated	T		1/3	0/0	(3)	(3)	0/0	0/0	(3)	1/3	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	3/0	2/2	3/3	0/0	4/4	4/4	4/4									
Anise	—	—		?		0/0	0/0	(2)	(2)	(2)	0/0	(2)	(2)	0/0	0/0	0/0	0/0	1/1	0/0	1/1	(1)	(1)	(2)	(2)	(2)	0/0	(1)	(1)	(1)									
Anise oil	—	084775-42-8		Xi		0/0	0/0	(3)	(3)	0/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	4/4	(3)	4/4	0/0	(1)	(1)	(1)	0/0								
Anisole	C ₇ H ₈ O	000100-66-3	100 %	Xi	X	1/4	3/4	1/0	4/4	0/0	2/3	(2)	3/3	4/4	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(3)	4/4	4/4	4/4	0/0	1/0	(1)	(1)	0/0								
Antifreeze agent (car)	—	—		Xn		1/1	1/1	3/3	(1)	1/0	0/0	1/1	1/1	1/1	0/0	0/0	0/0																					

5 von 24

6 von 24

CHEMICALS	thermoplastics																												fluoroplastics		elastomers		metals		COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C					
Carbon tetrafluoride	CF ₄	000075-73-0		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0						
Carbonyl chloride	→ see: Phosgene																																		
Carnauba wax	—	008015-86-9		—		1/1	1/1	1/1	(1)	1/0	0/0	(1)	1/1	0/0	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	(3)	(1)	(1)	0/0	1/1	(1)	(1)						
Castor oil	—	008001-79-4	100 %	Xi		1/1	1/1	1/0	1/0	(1)	1/0	(2)	1/1	1/1	0/0	1/0	3/0	1/1	0/0	(1)	1/1	1/1	3/0	1/0	1/0	0/0	(1)	1/1	1/1	1/1					
Caustic potash	→ see: Potassium hydroxide																																		
Cedar wood oil	—	008000-27-9		?		3/4	4/4	(2)	2/3	0/0	4/4	(2)	4/4	4/4	3/3	3/4	0/0	0/0	1/2	1/1	(1)	(2)	(4)	(2)	(3)	0/0	(1)	(1)	(1)						
Cesium bromide	CsBr	007787-69-1		Xi		1/1	1/1	(2)	(2)	(2)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(2)	(1)	0/0	(2)	0/0	0/0						
Cetyl alcohol	C ₁₈ H ₃₄ O	036653-82-4	100 %	Xi		1/1	1/1	4/4	(2)	1/0	0/0	(1)	1/1	0/0	1/0	1/1	3/3	1/1	1/1	1/1	1/1	1/0	1/0	1/0	0/0	(1)	1/1	1/1							
Chalk	CaCO ₃	—		—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1		calcium carbonate				
Chloral hydrate	C ₂ H ₃ Cl ₃ O ₂	000302-17-0	techn. pure	T/Xi		3/3	3/3	4/4	(3)	(4)	0/0	(3)	3/4	0/0	0/0	4/4	0/0	0/0	(1)	1/1	4/4	3/0	3/4	4/4	0/0	4/4	0/0	4/4	0/0	0/0					
Chloramine-T	C ₂ H ₃ ClNaSO ₂	000127-65-1	diluted	Xi		1/0	1/0	4/4	1/0	0/0	0/0	(3)	(3)	0/0	0/0	0/0	1/0	0/0	0/0	(1)	1/0	3/4	1/0	4/4	1/0	0/0	3/4	2/2	1/1	0/0					
Chloric acid	HClO ₃	007790-93-4	1 %	(C)		0/0	1/1	4/4	(3)	0/0	0/0	(3)	1/3	0/0	0/0	1/3	1/0	0/0	0/0	0/0	1/1	1/1	3/0	1/1	(3)	0/0	(3)	4/4	4/4	1/1					
Chloric acid	HClO ₃	007790-93-4	10 %	(O), C		1/0	0/0	4/4	(3)	0/0	0/0	4/4	4/4	0/0	0/0	1/3	0/0	0/0	0/0	1/1	1/1	3/0	3/0	4/4	0/0	4/4	4/4	4/4	4/4	1/1					
Chloric acid	HClO ₃	007790-93-4	20 %	(O), C		3/0	1/4	4/4	(3)	(4)	0/0	4/4	1/4	0/0	0/0	1/3	0/0	0/0	0/0	0/0	1/1	1/0	3/0	3/0	4/4	0/0	4/4	4/4	4/4	?					
Chloric acid, sodium salt	→ see: Sodium chlorate																																		
Chlorine	Cl ₂	007782-50-5	10 % wet	T		3/4	3/4	4/4	2/3	4/4	2/4	4/4	4/4	4/4	4/4	1/2	0/0	4/4	1/1	1/1	1/1	(2)	2/0	3/0	4/4	0/0	4/4	4/4	4/4	0/0					
Chlorine	Cl ₂	007782-50-5	97 %	T		4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/0	1/1	1/0	1/1	4/4	1/1	4/4	0/0	(3)	1/0	1/0	1/1					
Chlorine	Cl ₂	007782-50-5	steam	T		4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/0	1/1	1/0	1/1	4/4	1/1	4/4	0/0	(3)	1/0	1/0						
Chlorine dioxide	ClO ₂	010049-04-4		E, T		0/0	0/0	4/4	(3)	0/0	0/0	(3)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	1/0	(2)	4/4	1/0	4/4	0/0	3/4	3/4	3/4							
Chlorine trifluoride	ClF ₃	007790-91-2		(O, T)		0/0	0/0	4/4	(4)	4/4	(4)	4/4	(4)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(4)	4/4	(4)	4/4	0/0	(4)	(4)	(4)						
Chlorine water	Cl ₂ x H ₂ O	007782-50-5		(T)		3/0	0/4	4/4	4/4	4/4	4/4	4/4	3/4	4/4	0/0	3/3	3/0	3/3	1/1	(1)	1/1	1/1	3/0	1/0	4/4	0/0	4/4	2/0L	2/0L	0/0					
Chloro acetophenone, p-	C ₆ H ₄ ClO	000099-91-2		(Xn)		1/1	1/1	(2)	4/4	0/0	1/1	(2)	1/1	4/4	4/4	4/4	0/0	0/0	1/1	1/1	(2)	(2)	(3)	4/4	0/0	(1)	0/0	0/0							
Chloro-1-propene, 3-	→ see: Allyl chloride																																		
Chloro-2-propanone, 1-	→ see: Chloroacetone																																		
Chloroacetic acid	C ₂ H ₃ ClO ₂	000079-11-8	50 %	T, C		1/3	1/3	4/4	(4)	4/4	0/0	4/4	1/1	0/0	0/0	1/0	0/0	3/4	0/0	(1)	1/1	1/4	2/0	3/0	4/4	0/0	4/4	2/4	2/4	1/4					
Chloroacetic acid	C ₂ H ₃ ClO ₂	000079-11-8		T, C		1/1	1/1	4/4	3/4	4/4	1/2	4/4	1/2	2/4	4/4	3/4	4/4	3/4	1/1	1/1	1/1	4/4	3/0	3/0	4/4	0/0	4/4	4/4	4/4	4/4					
Chloroacetone	C ₃ H ₅ ClO	000078-95-5		(F, Xi)	X	0/0	0/0	(3)	(4)	(4)	(4)	(3)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(3)	1/0	4/4	4/4	0/0	(4)	0/0	0/0	0/0		Chloro-2-propanone, 1-; Acetyl chloride; Monochloroacetone				
Chlorobenzene	C ₆ H ₅ Cl	000108-90-7		Xn	X	3/4	3/4	4/4	4/4	1/4	4/4	1/0	3/4	4/4	4/4	4/4	4/4	4/4	1/1	1/1	1/1	1/1	4/4	3/4	4/4	0/0	1/1	1/1	1/1	1/1	Benzene chloride; Chlorobenzol; Monochlorobenzene (MCB); Phenyl chloride				
Chlorodifluoroethane	C ₂ H ₃ ClF ₂	000075-68-3		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	4/4	1/0	0/0	(3)	0/0	0/0						
Chlorodifluoromethane	CHClF ₂	000075-45-6		N, Xn		0/0	3/0	1/0	3/0	1/0	0/0	1/0	4/4	4/4	4/4	2/0	4/4	0/0	0/0	3/3	1/0	(3)	1/0	4/4	4/4	0/0	(3)	0/0	0/0		R 22				
Chloroethane, 1-	→ see: Monochloroethane																																		
Chloroethyl alcohol, 2-	C ₂ H ₅ ClO	000107-07-3	techn. pure	T+		1/1	0/0	4/4	4/4	0/0	0/0	3/4	4/4	0/0	0/0	4/4	0/0	0/0	0/0	1/1	1/0	1/3	3/0	4/4	4/4	0/0	(3)	1/0L	1/0L	1/0					
Chloroethylene	→ see: Vinyl chloride (VCM)																																		
Chlorofluorocarbons (CFC)	—	—		N		0/0	0/0	(2)	(3)	0/0	0/0	1/0	(3)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(3)	(3)	0/0	(3)	0/0	(3)	0/0	0/0		resistance depends on type				
Chlorofluoromethane	CH ₂ ClF	000593-70-4		N		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	4/4	4/4	0/0	(3)	0/0	0/0						
Chloroform	CHCl ₃	000067-66-3	100 %	Xn		3/4	4/4	3/4	4/4	4/4	4/4	4/4	3/4	4/4	4/4	4/4	4/4	4/4	2/3	1/1	1/1	1/1	4/4	3/4	4/4	0/0	(3)	1/1	1/1	1/1					
Chloroformyl chloride	→ see: Phosgene																																		
Chloronaphthalene, 1-	C ₁₀ H ₇ Cl	000090-13-1		Xn		0/0	0/0	(2)	(3)	0/0	0/0	(2)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	1/1	4/4	1/0	4/4	0/0	(2)	1/0	1/0						
Chloropentafluoroethane	C ₂ ClF ₅	000076-15-3		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0						
Chloroprene	C ₄ H ₃ Cl	000126-99-8		F, Xn	X	0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	3/4	4/4	0/0	(3)	0/0	0/0						
Chloropropylene, 3-	→ see: Allyl chloride																																		
Chlorosulfonic acid	ClHSO ₃	007790-94-5	techn. pure	C+		4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	3/0	4/4	4/4	0/0	0/0	1/0	3/4	4/4	4/4	4/4	0/0	3/3	3/4	3/4	1/0					
Chlorotoluene	C ₇ H ₇ Cl	—		Xn		0/0	0/0	(2)	4/4	0/0	(4)	(1)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	1/1	4/4	1/0	4/4	0/0	(3)	1/0	1/0	1/1	isomer not indicated in the source				
Chlorotrifluoromethane	CClF ₃	000075-72-9		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0							
Chromic acid	CrO ₃	001333-82-0	10 %	O, T, C, N		1/1	1/1	4/4	2/3	3/0	1/1	4/4	1/1	1/1	4/4	1/2	0/0	0/3	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	1/3	1/2	1/2	1/1	Chromium trioxide;				
Chromic acid	CrO ₃	001333-82-0	20 %	O, T, C, N		0/0	1/3	4/4	3/4	(4)	0/0	4/4																							

CHEMICALS	thermoplastics																												fluoroplastics		elastomers		metals				COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE /ETFE	FEP	PTFE	PVDF	EPDM	FPM /FKM	NBR	SI	AL	V2A	V4A	Hastelloy C							
Cinnamon oil	—	008007-80-5	—	Xn, Xi	—	3/4	4/4	(2)	2/3	0/0	4/4	(2)	4/4	4/4	3/3	4/4	0/0	1/2	1/1	(1)	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)									
Citric acid	C ₆ H ₈ O ₇	000077-92-9	10 %	Xi	1/1	1/1	1/1	1/2	1/3	1/1	2/4	1/1	1/2	1/1	1/3	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/0	1/1	1/1	1/1							
Citric acid	C ₆ H ₈ O ₇	000077-92-9	50 %	Xi	1/1	1/1	3/0	1/0	0/0	1/0	2/0	1/1	1/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	(1)	1/1	0/0	1/0	1/3	1/2	1/1							
Citric acid	C ₆ H ₈ O ₇	000077-92-9	saturated	Xi	1/1	1/1	3/0	1/0	0/0	1/0	2/0	1/1	1/1	0/0	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/0	(1)	1/1	0/0	1/0	1/3	1/2	1/1								
Citrus juices	—	—	aqueous	—	1/1	1/1	1/0	1/0	1/0	0/0	1/0	1/1	0/0	0/0	1/1	1/1	0/0	0/0	1/1	1/1	1/1	(1)	1/0	1/1	0/0	(2)	1/1	1/1									
Cleaning agents	—	—	?	?	1/1	1/1	1/0	1/1	1/1	0/0		1/1	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	(2)	0/0	1/1	1/1	1/1									
Clophen A60	—	011096-82-5	—	Xn, N	0/0	0/0	1/0	(3)	0/0	0/0	(2)	4/4	0/0	0/0	4/4	0/0	0/0	0/0	0/0	(1)	(2)	4/4	2/3	4/4	0/0	1/0	1/0	1/0	0/0	polychlorinated Biphenyls, PCB; Bayer							
Coal gas, without benzene	—	—	—	F+, T	X	1/0	1/0	1/0	1/0	(2)	1/0	(2)	1/0	1/0	0/0	1/0	1/0	0/0	0/0	(1)	1/0	1/0	4/4	1/0	3/0	0/0	1/1	1/1	1/1	0/0							
Cobalt dichloride	CoCl ₂	007646-79-9	aqueous	Xn	1/1	1/1	(2)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	1/0	1/0	0/0	(3)	0/0	0/0								
Cocoa	—	—	—	(—)	1/1	1/1	(2)	(1)	(2)	0/0	1/1	(2)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)									
Cocoa butter	—	008002-31-1	—	—	0/0	0/0	1/0	(1)	1/0	0/0	1/1	(2)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(1)	4/4	1/0	4/4	0/0	(1)	1/1	1/1								
Coconut butter	—	—	—	—	0/0	0/0	1/0	(2)	1/0	0/0	(2)	(2)	1/1	0/0	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/0	0/0	(1)	1/1	1/1								
Coconut fatty alcohol	—	068425-37-6	techn. pure	(Xi)	1/0	0/0	(1)	(2)	1/0	0/0	(2)	1/3	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	3/0	1/1	1/1	0/0	(1)	1/1	1/1									
Coconut oil	—	008001-31-8	techn. pure	—	1/3	1/3	1/0	(2)	1/0	0/0	(2)	1/1	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/1	1/1	0/0	(1)	1/1	1/1									
Cod-liver oil	—	008001-69-2	—	—	1/3	1/3	(2)	1/0	(2)	0/0	(2)	1/3	1/1	0/0	1/0	0/0	1/1	0/0	(1)	1/1	1/1	3/0	1/0	1/0	0/0	1/0	(1)	(1)	1/1								
Colza oil	—	008002-13-9	—	—	0/0	0/0	(2)	(2)	1/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/3	0/0	(1)	1/1	1/1									
Compressed air	—	—	oleaginous	—	1/0	0/0	(2)	(2)	(1)	0/0	(1)	3/0	0/0	0/0	3/0	0/0	0/0	0/0	(1)	1/1	1/1	(3)	(1)	(2)	0/0	1/1	1/1	1/1									
Condy's crystals	-> see: Potassium permanganate																																				
Copper acetate	C ₆ H ₆ CuO ₄	004180-12-5	aqueous	Xn	1/1	1/1	(3)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	(3)	3/3	0/0	4/4	1/1	1/1	1/1	verdigris						
Copper sulfate	CuSO ₄ x 5H ₂ O	007758-99-8	aqueous	Xn	1/1	1/1	1/0	1/0	(2)	1/0	1/0	1/1	1/1	1/0	1/3	1/0	1/1	1/1	(1)	1/1	1/1	1/0	1/1	2/0	0/0	4/4	1/1	1/1	1/1	blue stone							
Cotton oil	—	008001-29-4	techn. pure	?	0/0	0/0	1/0	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1)	3/0	1/0	1/0	0/0	(1)	1/1	1/1									
Creosote	—	—	—	(T)	1/1	1/1	3/0	(3)	0/0	0/0	(3)	3/4	0/0	1/0	3/0	4/4	0/0	0/0	(1)	1/1	(3)	4/4	(3)	1/0	0/0	(2)	1/1	1/1	0/0								
Creosote	-> see: Carbolineum																																				
Cresol (-mixtures)	C ₇ H ₈ O	001319-77-3	—	T, C	3/4	4/4	4/4	4/4	4/4	4/4	4/4	2/3	4/4	4/4	4/4	4/4	3/4	1/2	1/1	1/1	1/1	1/1	4/4	1/0	4/4	0/0	1/1	1/0	1/0	1/1							
Crotonaldehyde	C ₅ H ₈ O	004170-30-3	techn. pure	F, T	X	1/0	0/0	(2)	(4)	0/0	(4)	(2)	1/0	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/0	1/3	1/0	3/0	4/4	0/0	1/0	1/1	1/1	0/0							
Crude oil	—	—	100 %	(N)	0/0	1/3	1/0	(3)	1/0	0/0	1/0	1/3	3/0	1/0	1/0	3/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	3/3	0/0	(2)	(1)	(1)									
Cumene	C ₉ H ₁₂	000098-82-8	—	Xi	X	2/3	3/4	(2)	4/4	0/0	4/4	(2)	3/4	4/4	4/4	4/4	0/0	0/0	1/2	1/1	(1)	(2)	4/4	1/0	4/4	0/0	1/1	1/1	1/1	0/0							
Cupric chloride	CuCl ₂	007447-39-4	saturated	Xn	1/3	1/1	(3)	1/0	(2)	1/0	(2)	1/3	0/0	0/0	1/1	1/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/0	0/0	4/4	4/4	4/4	1/1								
Cupric nitrate	Cu(NO ₃) ₂	003251-23-8	saturated	O, Xn	1/1	1/1	1/0	(2)	(2)	1/0	1/0	1/1	1/0	0/0	1/0	1/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	4/4	0/0	4/4	1/1	1/1	1/1								
Cupric nitrate	Cu(NO ₃) ₂	003251-23-8	aqueous	O, Xn	0/0	0/0	(3)	(2)	(2)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/0	0/0	4/4	1/1	1/1	1/1								
Cuprous chloride	CuCl	007758-89-6	aqueous	Xn	0/0	0/0	(3)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/0	0/0	4/4	4/4	4/4	1/1								
Cuprous cyanide	CCuN	000544-92-3	saturated	T	1/1	1/1	(2)	(2)	(2)	0/0	(1)	1/3	0/0	0/0	1/0	1/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/0	0/0	(3)	1/1	1/1									
Curry	—	—	—	?	0/0	0/0	(2)	(2)	(2)	0/0	(1)	(2)	3/3	0/0	0/0	0/0	1/1	0/0	1/1	(1)	(1)	(2)	(2)	(2)	0/0	(1)	(1)	(1)		possibility of discoloration							
Cyanoethylene	-> see: Acrylonitrile																																				
Cyanomethane	-> see: Acetonitrile																																				
Cyclanon	—	—	—	(Xn, Xi)	1/1	1/1	1/0	(2)	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(2)	(2)	1/1	0/0	3/4	(1)	(1)	0/0	appliances for dyeing-mill; BASF							
Cyclohexane	C ₆ H ₁₂	000110-82-7	—	F	X	3/4	3/4	1/0	3/3	1/0	4/4	1/1	3/4	4/4	4/4	2/3	1/0	1/3	1/2	1/1	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0							
Cyclohexanol	C ₆ H ₁₂ O	000108-93-0	techn. pure	Xn	1/1	1/1	1/1	3/0	0/0	1/2	1/0	1/3	3/3	1/0	1/1	4/4	1/3	0/0	(1)	1/1	1/3	4/4	4/4	3/3	0/0	1/1	(1)	(1)	0/0								
Cyclohexanone	C ₆ H ₁₀ O	000108-94-1	techn. pure	Xn	X	1/3	3/4	1/0	4/4	(4)	3/4	1/0	2/4	4/4	4/4	4/4	4/4	0/0	(1)	1/1	1/3	4/4	4/4	4/4	0/0	1/0	(1)	(1)	0/0								
Cyclohexatriene	-> see: Benzene																																				
Cymene, p-	C ₁₀ H ₁₄	000099-87-6	—	F, Xn/Xi	X	0/0	0/0	(2)	4/4	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	4/4	0/0	1/1	1/1	1/1	0/0							
DDT (emulsion)	C ₁₄ H ₉ Cl ₅	000050-29-3	—	T	0/0	0/0	(2)	(3)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(2)	(3)	(3)	0/0	(2)	(2)	(2)	0/0								
Decahydronaphthalene	C ₁₀ H ₁₈	000091-17-8	—	Xn	1/3	3/4	1/0	4/4	3/0	4/4	1/0	3/4	4/4	4/4	1/2	3/0	3/4	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	1/1	(1)	(1)	0/0								
Decane	C ₁₀ H ₂₂	000124-18-5	—	Xn	X	0/0	0/0	(1)	(2)	(1)	(3)	1/1	(3)	0/0	0/0	0/0	0/0	0/0	1/1	(1)	(1)	4/4	1/0	3/3	0												

CHEMICALS	thermoplastics																			fluoroplastics				elastomers				metals				COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C		
Diaminoethane	C ₂ H ₈ N ₂	000107-15-3	techn. pure	C, Xn	X	1/1	1/3	1/0	(3)	0/0	1/0	1/0	1/1	0/0	0/0	3/0	4/4	0/0	0/0	(1)	1/1	(2)	3/0	3/0	4/4	0/0	1/1	(1)	(1)	0/0		
Diammonium sulfide	-> see: Ammonium sulfide																															
Diamyl phthalate	C ₁₈ H ₂₆ O ₄	000131-18-0	100 %	(T)		0/0	1/3	(1)	(4)	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	3/0	4/4	0/0	(1)	(1)	(1)	0/0		
Dibenzyl sebacate	C ₂₈ H ₂₆ O ₄	??		?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	2/0	(4)	4/4	0/0	(1)	(1)	(1)		plasticiser	
Dibromoethane, 1,2-	-> see: Ethylene dibromiden (EDB)																															
Dibromotetrafluoroethane	C ₂ Br ₂ F ₄	000124-73-2		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	4/4	3/0	3/0	0/0	(3)	0/0	0/0				
Dibutyl phthalate, n-	C ₁₆ H ₂₂ O ₄	000084-74-2	FR, 80°C	T		0	0	0	0	0	0	0	0	0	0	0	0	0	0	(1)	0	0	0	4/4	0	0	0	0	0	0/0	plasticiser	
Dibutyl phthalate, n-	C ₁₆ H ₂₂ O ₄	000084-74-2		T		1/3	3/3	1/0	4/4	1/0	0/2	1/0	2/2	4/4	1/0	4/4	4/4	0/4	1/1	(1)	1/1	1/3	3/0	2/3	4/4	0/0	(1)	1/1	1/1	0/0	plasticiser	
Dibutyl sebacate	C ₁₈ H ₃₄ O ₄	000109-43-3	techn. pure	—		1/0	1/3	1/0	(3)	0/0	0/0	(2)	1/0	4/4	0/0	4/4	4/4	4/4	0/0	(1)	1/1	1/0	3/0	4/4	4/4	0/0	(1)	(1)	(1)		plasticiser	
Dibutylamine	C ₈ H ₁₉ N	000111-92-2		Xn	X	0/0	0/0	(2)	(3)	0/0	(3)	(2)	(2)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)				
Dichloroacetic acid	C ₂ H ₂ Cl ₂ O ₂	000079-43-6	50 %	C		1/1	1/1	4/4	(4)	4/4	0/0	4/4	1/1	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	4/4	4/4	4/4	0/0	(4)	0/0	0/0	1/1		
Dichloroacetic acid	C ₂ H ₂ Cl ₂ O ₂	000079-43-6	techn. pure	C		1/3	3/3	4/4	(4)	4/4	0/0	4/4	1/3	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	4/4	4/4	4/4	0/0	(4)	0/0	0/0	1/1		
Dichlorobenzene, 1,2-	C ₆ H ₄ Cl ₂	000095-50-1		Xn		3/3	3/4	(1)	4/4	0/0	3/4	(2)	3/4	4/4	4/4	4/4	1/3	(1)	1/1	1/1	4/4	1/0	4/4	0/0	(1)	0/0	0/0					
Dichlorobenzene, 1,4-	C ₆ H ₄ Cl ₂	000106-46-7		Xn		2/3	3/4	1/0	4/4	0/0	2/3	(2)	3/4	4/4	4/4	4/4	0/0	0/0	1/3	(1)	1/0	1/1	4/4	1/0	4/4	0/0	(1)	0/0	0/0			
Dichlorodifluoromethane	CCl ₂ F ₂	000075-71-8	techn. pure	N		4/4	3/4	1/0	4/4	0/0	0/0	1/0	4/4	4/4	1/0	2/0	4/4	3/3	0/0	3/3	1/0	3/4	3/0	3/0	3/3	0/0	(3)	0/0	0/0	0/0		
Dichlorodifluoromethane	CCl ₂ F ₂	000075-71-8		N		4/4	3/4	1/0	4/4	0/0	0/0	1/0	4/4	4/4	1/0	2/0	4/4	3/3	0/0	3/3	1/0	3/4	3/0	3/0	3/3	0/0	(3)	0/0	0/0	0/0		
Dichloroethane	C ₂ H ₄ Cl ₂	—		F, T	X	3/3	2/4	3/0	4/4	4/4	4/4	1/0	3/4	4/4	4/4	4/4	4/4	1/1	1/1	1/1	1/1	4/4	3/0	4/4	0/0	1/3	1/1L	1/1L	?	isomer not indicated in the source		
Dichloroethylene	C ₂ H ₂ Cl ₂	—	techn. pure	F+, Xn	X	4/4	4/4	3/0	(4)	4/4	(4)	4/4	3/0	4/4	0/0	4/4	4/4	0/0	(1)	1/0	1/1	4/4	3/4	4/4	0/0	(3)	1/1L	1/1L	?	isomer not indicated in the source		
Dichlorofluoromethane	CHCl ₂ F	000075-43-4	100 %	N		0/0	3/0	1/0	3/0	0/0	0/0	1/0	4/4	4/4	3/0	4/4	4/4	3/3	0/0	(3)	1/0	(3)	4/4	4/4	4/4	0/0	(3)	0/0	0/0			
Dichlorohexafluorocyclobutane	C ₂ Cl ₂ F ₆	000356-18-3		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	(3)	1/0	0/0	(3)	0/0	0/0				
Dichloroisopropyl ether	C ₆ H ₁₂ Cl ₂ O	—		(Xn)		(4)	(4)	(2)	(3)	0/0	(4)	(3)	(3)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	4/4	4/4	0/0	(3)	0/0	0/0		isomer not indicated in the source		
Dichloropropane	C ₃ H ₆ Cl ₂	—	100 %	F, T/Xn	X	0/0	0/0	(3)	-4	(4)	(4)	(2)	4/4	4/4	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	4/4	(3)	4/4	0/0	(3)	0/0	0/0	0/0	isomer not indicated in the source	
Dichlorotetrafluoroethane	C ₂ Cl ₂ F ₄	000076-14-2		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0				
Dicyclohexyl phthalate	C ₂₆ H ₂₆ O ₄	000084-61-7	techn. pure	(Xn)		0/0	0/0	(1)	(3)	0/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	(3)	4/4	4/4	0/0	(1)	(1)	(1)		plasticiser		
Dicyclohexylamine (DCHA)	C ₁₂ H ₂₃ N	000101-83-7		C, Xn		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)			
Diesel fuel	—	—		Xn, N		1/3	0/0	1/1	3/3	1/1	0/0	1/1	1/3	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	1/1	(1)	(1)	0/0		
Diesel fuel for heating	—	—		Xn		3/3	3/4	1/0	3/3	1/0	2/3	1/1	1/3	3/4	1/2	1/1	3/3	1/1	1/1	1/1	1/1	4/4	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1		
Diesel oil	—	068334-30-5	100 %	(Xn)		1/3	1/4	1/1	3/3	1/1	0/0	1/1	1/3	3/4	0/0	1/3	3/3	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/1	0/0	1/1	(1)	(1)	0/0		
Diethanolamine (DEA)	C ₄ H ₁₁ NO ₂	000111-42-2	100 %	Xi		0/0	1/0	(2)	(3)	0/0	0/0	(2)	1/2	1/0	0/0	0/0	0/0	1/1	0/0	(1)	1/0	1/3	3/0	(3)	4/4	0/0	1/1	(1)	(1)	0/0		
Diethyl ethyl	C ₈ H ₁₈ O	000060-29-7	techn. pure	F+, Xn	X	3/4	4/4	1/1	4/4	1/0	4/4	1/2	4/4	4/4	4/4	4/4	4/4	1/2	1/1	1/1	1/4	4/4	4/4	4/4	0/0	1/1	1/1	1/1	0/0			
Diethyl ketone	-> see: Pentanone, 3-																															
Diethyl malonate	C ₇ H ₁₂ O ₄	000105-53-3		Xi		1/1	1/1	(2)	3/4	0/0	1/2	(2)	1/1	4/4	3/3	2/4	0/0	0/0	1/1	1/1	(1)	(3)	(2)	(4)	(3)	0/0	(1)	(1)	(1)			
Diethyl sebacate	C ₁₈ H ₂₆ O ₄	000110-40-7		Xi		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	2/0	3/0	4/4	0/0	(1)	(1)	(1)		plasticiser		
Diethyl succinate	C ₈ H ₁₆ O ₄	000123-25-1		—		0/0	0/0	(2)	(4)	0/0	0/0	(3)	(2)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(2)	4/4	4/4	0/0	(1)	(1)	(1)				
Diethylamine	C ₄ H ₁₁ N	000109-89-7	techn. pure	F, C, Xn	X	0/0	0/0	(2)	(3)	0/0	0/0	(2)	1/2	0/0	0/0	3/0	0/0	0/0	(1)	1/0	1/4	2/0	4/4	4/4	0/0	(1)	1/1	1/1	0/0			
Diethylbenzene	C ₁₀ H ₁₄	000135-01-3		Xi		3/4	4/4	(1)	3/4	0/0	4/4	(2)	4/4	4/4	4/4	0/0	0/0	1/2	1/1	(1)	(2)	4/4	1/0	4/4	0/0	1/1	1/1	1/1				
Diethylene glycol	C ₄ H ₁₀ O ₃	000111-46-6		T		1/1	1/1	3/0	2/3	0/0	1/1	(2)	1/1	2/2	2/2	3/4	0/0	1/1	1/1	1/1	1/1	(2)	1/0	1/0	3/0	0/0	1/1	(1)	(1)	0/0		
Diethylene glycoether	—	—		(Xn)		1/1	1/1	3/0	3/4	0/0	1/1	(2)	1/1	4/4	3/3	3/4	0/0	0/0	1/1	1/1	(1)	(2)	3/0	(3)	3/3	0/0	(1)	(1)	(1)			
Difluoroethane	C ₂ H ₂ F ₂	000075-37-6		(E), F+		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	4/4	1/0	0/0	(3)	0/0	0/0				
Difluoromethane	CH ₂ F ₂	000075-10-5		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	4/4	1/0	0/0	(3)	0/0	0/0				
Diglycolic acid	C ₄ H ₆ O ₅	000110-99-6	aqueous	Xn		1/1	1/1	(3)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/														

CHEMICALS	thermoplastics																												fluoroplastics		elastomers		metals		COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C					
Dimethylaniline	C ₉ H ₁₁ N	—		T		0/0	0/0	(3)	4/4	0/0	0/0	(2)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0	isomer not indicated in the source				
Dinitro ethylene glycol	C ₂ H ₄ (NO ₂) ₂	000628-96-6	diluted	(E, T+)		0/0	0/0	(3)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	4/4	4/4	0/0	0/0	(1)	(1)	(3)	1/0	1/0	4/4	0/0	0/0	(1)	(1)	0/0					
Dinonyl phthalate (DNP)	C ₂₆ H ₄₂ O ₄	000084-76-4	techn. pure	Xn		3/0	0/0	(2)	3/0	0/0	(2)	1/3	0/0	0/0	4/4	0/0	0/0	0/0	0/0	(1)	1/0	(2)	(3)	4/4	4/4	0/0	(1)	(1)	(1)		plasticiser				
Diocetyl adipate	C ₂₂ H ₄₂ O ₄	000103-23-1		?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)		plasticiser				
Diocetyl phthalate (DOP)	C ₂₆ H ₃₈ O ₄	000117-81-7	techn. pure	Xn		4/4	4/4	1/0	4/4	1/0	1/0	(2)	4/4	4/4	1/0	4/4	4/4	0/0	0/0	1/1	1/0	(2)	3/0	2/3	4/4	0/0	(1)	(1)	(1)		plasticiser				
Diocetyl sebacate	C ₂₆ H ₅₀ O ₄	002432-87-3	—	—		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	2/0	3/0	4/4	0/0	(1)	(1)	(1)		plasticiser				
Dioxane	C ₄ H ₈ O ₂	000123-91-1		F, Xn	X	2/2	2/3	1/0	4/4	1/0	2/3	1/2	3/3	4/4	2/3	3/4	4/4	1/3	1/1	1/1	3/3	2/0	4/4	4/4	0/0	1/1	1/0	1/0	0/0						
Diphenyl ether	C ₁₂ H ₁₀ O	000101-84-8		Xn/Xi		0/0	1/0	3/0	(3)	(4)	0/0	1/1	4/4	4/4	0/0	0/0	4/4	4/4	0/0	(1)	1/0	(2)	4/4	3/0	4/4	0/0	(1)	(1)	(1)	0/0					
Diphenylamine	C ₁₂ H ₁₁ N	000122-39-4		T		0/0	0/0	0/0	(3)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(3)	(3)	(4)	0/0	(1)	(1)	(1)	0/0						
Diphyl	—	008004-13-5		?		0/0	0/0	1/1	(3)	4/4	0/0	1/1	4/4	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	3/0	4/4	0/0	(1)	(1)	(1)		mixture with diphenyl and diphenyl ether; Bayer				
Dipropyl ketone	C ₇ H ₁₄ O	000123-19-3		—	X	0/0	0/0	(3)	(4)	(4)	(4)	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(4)	4/4	0/0	(1)	(1)	(1)						
Dipropylene glycol	C ₈ H ₁₆ O ₃	025265-71-8		Xi		1/1	1/1	(2)	2/3	0/0	1/1	1/0	1/1	1/1	2/2	2/3	0/0	0/0	1/1	1/1	(1)	(2)	4/4	3/0	3/3	0/0	(1)	(1)	(1)						
Dipropylene glycol (mono)methyl ether	C ₈ H ₁₆ O ₂	—		—	X	0/0	0/0	(3)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)	0/0	isomer not indicated in the source					
Disodium phosphate	Na ₂ HPO ₄	007558-79-4		(Xi)		1/1	1/1	1/0	(2)	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	(1)	0/0	(1)	1/1	1/1	0/0		latex				
Dispersion of rubber	—	—		?		0/0	0/0	1/0	(2)	(2)	0/0	2/3	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(3)	(1)	(2)	0/0	(3)	(1)	(1)						
Dithionous acid, disodium salt	-> see: Sodium hydrosulfite																																		
Divinylene oxide	-> see: Furan																																		
Dope, viscous ~	—	—		(Xn, Xi)		1/1	1/1	4/4	(3)	0/0	0/0		1/1	0/0	0/0	1/1	1/1	0/0	0/0	(1)	1/1	1/1	(3)	(2)	4/4	0/0	(3)	3/4	2/4	0/0					
Emulsifiers	—	—		?		0/0	0/0	(2)	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(2)	(2)	(3)	0/0	0/0	K	K						
Emulsions for fotos	—	—		?		1/0	0/0	1/0	(2)	(2)	0/0	1/0	1/1	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	(2)	(2)	(1)	0/0	(2)	0/0	0/0						
Ephetin	—	—	10% in water	?		0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0					
Epichlorhydrin	C ₃ H ₅ ClO	000106-89-8	100 %	F, T	X	1/0	1/0	4/4	(4)	0/0	(4)	1/0	2/2	0/0	0/0	4/4	4/4	0/0	0/0	(1)	1/0	(3)	3/0	4/4	4/4	0/0	(3)	0/0	0/0	0/0					
Epoxyp propane, 1,2-	-> see: Propylene oxid																																		
Ethanal	-> see: Acetaldehyde																																		
Ethanedioic acid	-> see: Oxalic acid																																		
Ethanenitrile	-> see: Acetonitrile																																		
Ethanoyl chloride	-> see: Acetyl chloride																																		
Ethoxybenzene	C ₈ H ₁₀ O	000103-73-1		?		0/0	0/0	(2)	(4)	0/0	(3)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)		Ethyl phenyl ether; Phenyl ethyl ether; Phenetole				
Ethyl acetate	C ₄ H ₈ O ₂	000141-78-6	100 %	F	X	1/3	3/4	1/0	4/4	4/4	4/4	1/1	1/3	4/4	4/4	4/4	4/4	4/4	1/2	1/1	1/1	3/3	3/0	4/4	4/4	0/0	1/1	(1)	(1)	1/0					
Ethyl acrylate	C ₈ H ₈ O ₂	000140-88-5	100 %	F, Xn	X	4/4	4/4	1/0	(4)	(4)	(4)	(2)	4/4	0/0	0/0	4/4	4/4	0/0	0/0	1/1	1/0	3/0	4/4	4/4	4/4	0/0	(1)	(1)	(1)	1/0					
Ethyl alcohol	C ₂ H ₆ O	000064-17-5	40 %	—	X	1/1	1/2	1/0	1/2	1/1	1/2	1/2	1/1	2/3	1/2	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/1	1/1	1/1					
Ethyl alcohol	C ₂ H ₆ O	000064-17-5	50 %	—	X	1/1	1/1	1/0	1/1	1/1	1/0	1/2	1/1	1/0	1/0	1/0	3/0	0/0	0/0	1/1	1/1	1/1	1/0	(2)	1/1	0/0	1/1	1/1	1/1	1/1					
Ethyl alcohol	C ₂ H ₆ O	000064-17-5	96 %	F	X	1/0	1/3	1/0	1/3	1/1	1/2	1/2	1/1	3/4	1/2	1/3	3/0	1/3	1/1	1/1	1/1	1/1	1/0	3/0	3/3	0/0	1/1	1/1	1/1	1/1					
Ethyl aldehyde	-> see: Acetaldehyde																																		
Ethyl benzoate	C ₉ H ₁₀ O ₂	000093-89-0		Xn		2/2	3/3	(2)	4/4	0/0	2/3	(2)	2/3	4/4	4/4	4/4	0/0	4/4	1/2	1/1	1/0	(3)	(3)	(3)	4/4	0/0	(1)	(1)	(1)						
Ethyl butyrate	C ₈ H ₁₂ O ₂	000105-54-4		F	X	2/3	2/4	(2)	4/4	0/0	3/4	(2)	2/4	4/4	4/4	4/4	0/0	0/0	1/2	1/1	(1)	(2)	(3)	(4)	4/4	0/0	(1)	(1)	(1)						
Ethyl chloride	-> see: Monochloroethane																																		
Ethyl chloroacetate	C ₄ H ₇ ClO ₂	000105-39-5	techn. pure	T/Xi		1/1	1/1	(3)	4/4	(4)	(4)	(3)	1/1	4/4	0/0	3/4	3/4	0/0	0/0	(1)	1/1	1/4	3/0	4/4	4/4	0/0	3/4	0/0	0/0	0/0					
Ethyl cyanoacetate	C ₅ H ₇ NO ₂	000105-56-6		Xn/Xi		1/1	1/1	0/0	3/4	0/0	1/1	(2)	1/1	2/4	3/3	3/4	0/0	0/0	1/1	1/1	(1)	(3)	(2)	(3)	(3)	0/0	(2)	(1)	(1)	0/0					
Ethyl formate	C ₃ H ₆ O ₂	000109-94-4		F	X	0/0	0/0	0/0	(4)	0/0	(4)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	(3)	(4)	4/4	0/0	(1)	(1)	(1)						
Ethyl lactate	C ₅ H ₁₀ O ₃	000097-64-3		—	X	1/1	1/1	(2)	3/4	0/0	1/1	(2)	1/1	3/4	3/3	3/4	0/0	0/0	1/1	1/1	(1)	3/0	(3)	(3)	(3)	0/0	(1)	(1)	(1)						
Ethyl mercaptan	C ₂ H ₆ S	000075-08-1		F, Xn	X	0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)						
Ethyl phenyl ether</																																			

CHEMICALS	thermoplastics																												fluoroplastics				elastomers				metals				COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C											
Ethylene oxide	C ₂ H ₄ O	000075-21-8		F+, T	X	2/3	3/3	3/0	3/4	1/0	3/4	1/0	3/3	4/4	1/1	3/4	0/0	0/0	1/1	1/1	(1)	1/1	4/4	4/4	0/0	1/1	(1)	(1)	(1)	0/0											
Ethylenediaminetetraacetic acid (EDTA)	C ₁₀ H ₁₆ N ₂ O ₈	000060-00-4		Xi		1/1	1/1	(2)	(2)	(2)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	(2)	(1)	0/0	(3)	0/0	0/0	0/0											
Ethylhexanol-1	C ₈ H ₁₈ O	000104-76-7		Xn/Xi		0/0	1/3	(2)	(2)	(1)	1/0	1/0	1/0	3/0	0/0	1/0	4/4	0/0	0/0	(1)	1/1	(1)	1/0	1/0	1/0	0/0	(1)	(1)	(1)	1/1											
Ethyne	-> see: Acetylene																																								
Eucalyptus oil	—	008000-48-8		?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	3/3	0/0	(1)	(1)	(2)	4/4	(3)	(4)	0/0	(1)	(1)	(1)												
Exhaust gases, alkaline	—	—		?		1/1	0/0	(2)	0/0	0/0	0/0	(1)	1/1	0/0	0/0	1/1	0/0	0/0	0/0	0/0	1/1	1/4	1/0	1/0	1/0	0/0	(2)	(1)	(1)												
Exhaust gases, containing carbon dioxide	—	—	small	?		1/1	0/0	(1)	(1)	(1)	1/1	(1)	1/1	(1)	1/1	(1)	1/1	(1)	1/1	1/1	1/1	1/0	1/0	(1)	(1)	(1)	(1)	(1)	0/0												
Exhaust gases, containing hydrochloric acid	—	—	each	?		1/1	0/0	(3)	0/0	0/0	0/0	(4)	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/0	1/0	3/0	0/0	(4)	2/2L	2/2L	3/3												
Exhaust gases, containing hydrogen fluoride	—	—	small	?		1/1	0/0	(3)	(3)	0/0	0/0	(4)	1/1	0/0	0/0	1/1	0/0	0/0	(2)	1/1	1/1	1/1	1/0	1/0	1/0	0/0	(4)	(2)	(2)	1/1											
Exhaust gases, containing nitrose	—	—	small	?		1/1	0/0	(3)	0/0	0/0	0/0	(4)	1/3	0/0	0/0	1/1	0/0	0/0	(2)	1/1	1/1	1/1	1/0	1/0	(3)	0/0	(2)	(1)	(1)												
Exhaust gases, containing sulfur dioxide	—	—	small	?		1/1	0/0	(2)	0/0	0/0	0/0	(4)	1/1	0/0	0/0	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	3/0	0/0	(4)	1/1	1/1	0/0											
Exhaust gases, containing sulfur trioxide	—	—	small	?		1/1	0/0	(4)	0/0	0/0	0/0	(4)	4/4	0/0	0/0	1/1	0/0	0/0	(2)	(2)	1/1	1/1	1/0	1/0	4/4	0/0	(4)	(2)	(1)	0/0											
Exhaust gases, containing sulfuric acid	—	—	each	?		1/1	0/0	(4)	0/0	0/0	0/0	(4)	1/3	0/0	0/0	1/1	0/0	0/0	(2)	1/1	1/1	1/1	1/0	1/0	4/4	0/0	(4)	(2)	(1)	0/0											
Fat, animal	—	—		—		0/0	0/0	1/0	(2)	1/0	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	(1)	1/1	1/1												
Fat, mineral	—	—		(—)		0/0	0/0	1/0	(2)	(1)	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	(4)	(1)	1/0	0/0	(1)	1/1	1/1												
Fat, vegetable	—	—		—		0/0	0/0	1/0	(2)	1/0	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	(1)	1/1	1/1												
Fats, edible oil	—	—		—		0/0	1/0	1/0	1/0	1/0	1/0	1/1	3/0	0/0	1/0	1/0	3/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	(1)	1/1	1/1	1/1											
Fatty alcohol sulfonates	—	—	aqueous	(Xn, Xi)		1/1	0/0	1/0	(2)	1/0	0/0	1/1	1/3	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	(2)	(2)	1/1	0/0	3/4	1/0	1/0	0/0	detergents										
Ferric chloride	FeCl ₃	007705-08-0	saturated	Xn		1/1	1/1	3/0	1/0	0/0	1/0	4/4	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	(1)	1/1	1/1	0/0	4/4	4/4	4/4	1/1												
Ferric nitrate	Fe(NO ₃) ₃	010421-48-4	aqueous	(O, Xn)		1/1	1/1	(2)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	0/0	4/4	1/1	1/1	1/1											
Ferric nitrate	Fe(NO ₃) ₃	010421-48-4	saturated	O, Xn		1/1	1/1	1/0	1/0	0/0	1/0	(3)	1/1	1/1	0/0	1/1	1/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	0/0	4/4	1/1	1/1	1/1												
Ferric sulfate	Fe ₂ (SO ₄) ₃	010028-22-5	saturated	Xi		1/1	1/1	(2)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	0/0	4/4	1/1	1/1	1/1											
Ferrous chloride	FeCl ₂	007758-94-3	saturated	Xn		1/1	1/1	3/0	1/0	(2)	1/0	(3)	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	(1)	1/1	(1)	0/0	4/4	(2)	1/1	1/1											
Ferrous sulfate	FeSO ₄	007720-78-7	saturated	(Xn)		1/1	1/1	(2)	1/0	0/0	1/0	(3)	1/1	1/0	0/0	1/1	1/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	0/0	4/4	1/1	1/1	1/1											
Ferrous sulfate	FeSO ₄	007720-78-7	aqueous	(Xn)		1/1	1/1	(2)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	0/0	4/4	1/1	1/1	1/1											
Ferrous sulfate	FeSO ₄	007720-78-7		Xn		1/1	1/1	(2)	1/0	(2)	0/0	(3)	1/1	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	(1)	1/0	(1)	0/0	4/4	1/1	1/1	1/1											
Fire-damp	—	—		F+	X	0/0	0/0	1/0	(2)	(1)	0/0	(1)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	4/4	1/0	1/0	0/0	1/1	(1)	(1)		mainly methane										
Fixer for fotos	—	—		?		1/0	1/1	1/0	(2)	0/0	0/0	1/0	1/1	0/0	0/0	1/3	1/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/0	0/0	(2)	1/0	1/0												
Fluid 101, 100°C	—	—		?		0	0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	0	0	0	0	3	0	0	0	0		Brake fluid, based on polyglycoles										
Fluorides	—	—		T		1/1	1/1	(2)	1/1	(2)	1/1	(1)	1/1	2/2	1/1	1/1	0/0	0/0	1/1	1/1	(1)	(1)	(2)	(2)	(1)	0/0	0/0	K	K												
Fluorine	F ₂	007782-41-4		O, T+, C+		4/4	4/4	4/4	4/4	4/4	3/4	4/4	4/4	4/4	4/4	1/2	0/0	4/4	1/3	1/2	1/2	4/4	4/4	3/0	4/4	0/0	4/4	(4)	(4)	0/0											
Fluorobenzene	C ₆ H ₅ F	000462-06-6		F, (Xn)	X	0/0	0/0	(2)	(4)	0/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	3/0	4/4	0/0	(1)	0/0	0/0												
Fluorocarbons	—	—		?		0/0	0/4	(2)	(3)	(2)	0/0	(2)	(3)	4/4	0/0	0/0	0/0	0/4	1/1	0/0	1/1	(3)	(3)	(3)	0/0	(1)	0/0	0/0			resistance depends on type										
Formaldehyde solution	CH ₂ O	000050-00-0	10 %	Xn		1/1	1/1	3/3	1/2	1/0	1/2	1/2	1/1	3/4	2/3	2/3	3/3	1/3	1/1	1/1	1/1	1/1	1/0	3/0	(2)	0/0	1/1	1/1	1/1	1/1											
Formaldehyde solution	CH ₂ O	000050-00-0	30 %	T		1/1	1/1	3/3	1/2	1/0	0/0	1/2	1/1	4/4	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	3/0	1/0	0/0	1/1	1/1	1/1	1/1											
Formaldehyde solution	CH ₂ O	000050-00-0	40 %	T		1/2	2/3	1/3	1/2	1/0	1/2	1/2	1/2	4/4	2/3	2/3	3/3	0/4	1/1	1/1	1/1	1/1	1/0	3/0	(3)	0/0	1/1	1/1	1/1	1/1											
Formamide	CH ₃ NO	000075-12-7	techn. pure	T/Xi		1/1	1/1	1/0	(3)	0/0	0/0	1/0	1/1	1/0	0/0	4/4	4/4	0/0	0/0	1/0	1/1	(3)	3/0	2/3	4/4	0/0	1/1	1/1	1/1	1/1											
Formic acid	CH ₂ O ₂	000064-18-6	50 %	C		1/1	1/2	4/4	3/3	0/0	1/2	4/4	1/2	3/3	2/2	2/3	0/0	1/3	1/1	1/1	1/1	1/1	3/4	4/4	4/4	0/0	(3)	1/3	1/2	1/1	Hydrogen carboxylic acid; Methanoic acid; Aminic acid; Formylic acid										
Formic acid	CH ₂ O ₂	000064-18-6	98-100 %	C		1/1	1/2	4/4	3/4	0/0	1/3	4/4	1/3	3/4	3/4	1/3	3/4	1/1	(1)	1/1	1/1	3/4	4/4	4/4	0/0	1/0	1/3	1/2	1/0												
Formic acid	CH ₂ O ₂	000064-18-6	3 %	Xi		1/1	1/2	3/4	1/2	1/0	1/2	2/4	1/2	1/2	2/2	2/3	0/0	0/0	1/1	1/1	1/1	1/1	3/0	(3)	4/4	0/0	(3)	1/2	1/1	1/1											
Freon 11	-> see: Trichlorofluoromethane																																								
Freon 11	-> see: Trichlorofluoromethane																																								
Freon 112	-> see: Tetrachlorodifluoroethane																																								
Freon 112	-> see: Tetrachlorodifluoroethane																																								
Freon 113	-> see: Trichlorotrifluoroethane																																								
Freon 113	-> see: Trichlorotrifluoroethane																																								
Freon 114	-> see: Dichlorotetrafluoroethane																																								
Freon 114	-> see: Dichlorotetrafluoroethane																																								
Freon 114 B2	-> see: Dibromotetrafluoroethane																																								
Freon 114 B2	-> see: Dibromotetrafluoroethane																																								
Freon 115	-> see: Chloropentafluoroethane																																								
Freon 115	-> see: Chloropentafluoroethane																																								
Freon 12	->																																								

CHEMICALS	thermoplastics																												fluoroplastics				elastomers				metals				COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C											
Freon 12	-> see: Dichlorodifluoromethane																																								
Freon 13	-> see: Chlorotrifluoromethane																																								
Freon 13	-> see: Chlorotrifluoromethane																																								
Freon 13 B1	-> see: Bromotrifluoromethane																																								
Freon 13 B1	-> see: Bromotrifluoromethane																																								
Freon 14	-> see: Carbon tetrafluoride																																								
Freon 14	-> see: Carbon tetrafluoride																																								
Freon 142b	-> see: Chlorodifluoroethane																																								
Freon 142b	-> see: Chlorodifluoroethane																																								
Freon 152a	-> see: Difluoroethane																																								
Freon 152a	-> see: Difluoroethane																																								
Freon 21	-> see: Dichlorofluoromethane																																								
Freon 21	-> see: Dichlorofluoromethane																																								
Freon 218	-> see: Octafluoropropane																																								
Freon 218	-> see: Octafluoropropane																																								
Freon 22	-> see: Chlorodifluoromethane																																								
Freon 22	-> see: Chlorodifluoromethane																																								
Freon 31	-> see: Chlorofluoromethane																																								
Freon 31	-> see: Chlorofluoromethane																																								
Freon 32	-> see: Difluoromethane																																								
Freon 32	-> see: Difluoromethane																																								
Freon C 318	-> see: Perfluorocyclobutane																																								
Freon C 318	-> see: Perfluorocyclobutane																																								
Freon C316	-> see: Dichlorohexafluorocyclobutane																																								
Freon C316	-> see: Dichlorohexafluorocyclobutane																																								
Frigen 12	-> see: Dichlorodifluoromethane																																								
Frigen 12	-> see: Dichlorodifluoromethane																																								
Frigen 21	-> see: Dichlorofluoromethane																																								
Frigen 21	-> see: Dichlorofluoromethane																																								
Frigen 22	-> see: Chlorodifluoromethane																																								
Frigen 22	-> see: Chlorodifluoromethane																																								
Fructose	C ₆ H ₁₂ O ₆	000057-48-7	each	—		1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1										
Fruit pulp	—	—	—	—		1/1	1/1	(2)	1/1	1/1	0/0	1/1	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/1	0/0	(2)	1/1	1/1	1/1	1/1										
Fruit wine	—	—	—	—		1/1	1/1	(2)	(1)	1/1	0/0	1/1	1/0	0/0	0/0	1/0	0/0	0/0	1/1	1/1	(1)	1/1	1/0	(1)	1/0	0/0	(2)	1/1	1/1	1/1	1/1										
Fuel + 20% ethyl alcohol	—	—	—	F, T	X	0/0	0/0	(1)	4/4	0/0	(4)	2/2	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	3/0	3/0	0/0	(1)	1/1	1/1												
Fuel + 20% methyl alcohol	—	—	—	F, T	X	0/0	0/0	(1)	4/4	0/0	(4)	2/2	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	(3)	4/4	0/0	(1)	1/1	1/1												
Fuel, Normal	—	—	—	F, T	X	0/0	0/0	1/0	3/0	1/1	(4)	2/2	3/4	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	3/0	0/0	1/1	1/1	1/1												
Fuel, piston engine (JP)	—	—	—	(Xn)		0/0	0/0	(1)	(3)	0/0	0/0	1/0	1/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	1/0	1/0	0/0	(1)	(1)	(1)													
Fuel, Super	—	—	—	F, T	X	0/0	0/0	1/0	4/4	(2)	(4)	2/2	3/4	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	3/0	0/0	1/1	1/1	1/1												
Furalmethanal, 2-	-> see: Furfural																																								
Furan	C ₄ H ₄ O	000110-00-9		F+, T+	X	0/0	0/0	(3)	4/4	0/0	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	4/4	4/4	0/0	(1)	(1)	(1)	0/0	Furfuran; Divinylene oxide; Oxacyclopentadiene										
Furancarboxyaldehyde, 2-	-> see: Furfural																																								
Furfural	C ₅ H ₄ O ₂	000098-01-1		T		1/3	3/4	3/3	(3)	1/0	0/0	2/0	4/4	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	1/2	3/0	4/4	4/4	0/0	1/1	1/1	1/1	0/0	Furancarboxyaldehyde, 2-; Furaldehyde, 2-; Furalmethanal, 2-										
Furfuryl alcohol	C ₅ H ₆ O ₂	000098-00-0	techn. pure	Xn		1/1	1/3	1/0	(3)	1/0	0/0	1/0	1/3	0/0	4/4	4/4	4/4	3/4	0/0	(1)	1/1	1/3	3/0	(3)	4/4	0/0	(1)	(1)	(1)	0/0											
Gallic acid	C ₇ H ₆ O ₅ x H ₂ O	000149-91-7		Xi		1/1	1/1	1/0	(3)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/4	3/0	1/0	3/0	0/0	1/0	1/1	1/1	1/1											
Gas liquor	—	—	—	?		0/0	0/0	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(3)	(2)	(2)	0/0	(2)	0/0	0/0												
Gas oil	—	—	—	(Xn)		0/0	0/0	(1)	(2)	1/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	1/1	(1)	(1)												
Gas, natural	—	—	—	F+	X	0/0	0/0	0/10	1/0	1/0	0/0	1/0	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	4/4	1/0	1/0	0/0	1/1	(1)	(1)		mainly methane										
Gasoline	—	008006-61-9		(F, Xn)	X	0/0	0/0	(1)	3/4	(2)	0/0	1/2	3/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	3/0	0/0	1/1	(1)	(1)												
Gasoline	C ₈ H ₁₂ - C ₁₂ H ₂₆	086290-81-5		F, Xn, N	X	2/3	3/4	1/0	3/3	(2)	2/3	1/2	3/4	4/4	3/3	2/4	0/0	0/4	1/1	1/1	1/1	1/1	4/4	(1-3)	3/0	0/0	1/1	1/1	1/1	1/1	fuel, lead-free										
Gearbox oil, EP (Hypoid), 110°C	—	—	—	?		0	0	1	1	1	0	4	(3)	0	0	0	0	0	0	0	(2)	0	4/4	0	4/4	0	(1)	1	1	0/0											
Gelatin	—	009000-70-8	each	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/0	1/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0											
Genantin	—	—	—	Xn		0/0	0/0	3/3	(2)	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/0	1/2	1/1	0/0	1/1	1/1	1/1		antifreeze agent , based on glycol; Clariant										

CHEMICALS	thermoplastics																												fluoroplastics		elastomers		metals		COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C					
Ginger	—	—	ground	?	—	0/0	0/0	(2)	(2)	(2)	0/0	(1)	(2)	4/4	0/0	0/0	0/0	3/3	0/0	(1)	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)						
Glucose	C ₆ H ₁₂ O ₆	000050-99-7	each	—	—	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1					
Glue (bone glue)	—	—	each	—	—	1/0	1/1	(1)	(1)	1/1	0/0	(2)	1/1	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	(1)	(1)	1/0	1/0	0/0	(3)	1/1	1/1	0/0					
Glycerol	C ₃ H ₈ O ₃	000056-81-5	each	Xi	—	1/1	1/1	1/0	3/3	1/0	1/1	1/0	1/1	1/1	1/1	1/1	2/3	1/1	1/1	1/1	1/1	1/0	1/1	1/0	0/0	1/1	1/1	1/1	1/1	1/1	Glycerin; Propanetriol, 1,2,3-; Trihydroxypropane, 1,2,3-				
Glycine	C ₂ H ₅ NO ₂	000056-40-6	10 %	—	—	1/1	1/1	1/1	1/1	(1)	0/0	1/1	1/1	0/0	0/0	1/3	1/3	0/0	1/1	1/1	1/1	1/1	1/1	1/0	3/3	0/0	(2)	(2)	(2)	0/0	Glycocol; Aminoacetic acid				
Glycolic acid	C ₂ H ₄ O ₃	000079-14-1	37 %	Xn	—	1/1	0/0	4/4	(2)	0/0	0/0	(3)	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/3	1/0	2/0	1/0	0/0	1/0	1/3	1/3	1/1					
Glycolic acid	C ₂ H ₄ O ₃	000079-14-1	70 %	C, Xn	—	1/1	1/1	4/4	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(2)	1/0	3/0	(2)	0/0	(2)	1/3	1/3	1/1						
Glysantin	—	—	—	Xn	—	1/1	1/1	3/3	(2)	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/2	1/1	0/0	1/1	1/1	1/1		antifreeze agent, based on glycol; BASF				
Gum tragacanth	—	009000-65-1	—	—	—	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	(1)	1/1	1/1						
HD-Oil motor oil, without aromatics	—	—	?	?	—	1/0	1/3	1/0	1/1	1/1	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	4/4	(1)	3/3	0/0	1/1	1/1	1/1							
Helium	He	007440-59-7	—	—	—	0/0	0/0	1/0	(1)	1/1	0/0	1/1	1/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(1)	1/1	(1)	1/0	1/0	1/0	0/0	1/1	1/1	1/1					
Henkel-P3-solution	—	—	?	?	—	1/1	1/1	(2)	(2)	(1)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(2)	(2)	1/0	0/0	0/0	1/1	1/1		cleaner				
Heptane, normal	C ₇ H ₁₆	000142-82-5	—	F, Xn	X	2/3	3/4	1/0	1/2	1/0	3/3	1/2	2/4	4/4	1/2	2/3	4/4	1/0	1/1	1/1	1/1	1/1	4/4	1/1	1/1	0/0	1/1	1/1	1/1	0/0					
Heptanol, 1-	C ₇ H ₁₆ O	000111-70-6	—	Xn	—	0/0	0/0	(2)	(2)	(1)	0/0	(1)	(2)	0/0	0/0	0/0	0/0	1/3	0/0	(1)	(1)	(1)	4/4	(1)	1/0	0/0	(1)	(1)	(1)						
Heptanone	C ₇ H ₁₄ O	—	—	(Xn)	X	0/0	0/0	(3)	(4)	(4)	(4)	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(4)	(4)	4/4	0/0	(1)	(1)	(1)		isomer not indicated in the source				
Hexachlorbenzene (HCB)	C ₆ Cl ₆	000118-74-1	—	T	—	0/0	0/0	(3)	(4)	0/0	(4)	1/0	(3)	0/0	0/0	0/0	0/0	1/1	0/0	(1)	(2)	0/0	4/4	(3)	4/4	0/0	(1)	0/0	0/0						
Hexachlorocyclohexane (alpha-BHC)	C ₆ H ₆ Cl ₆	000319-84-6	—	T	—	0/0	0/0	(3)	(4)	0/0	0/0	(3)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	0/0	4/4	1/0	4/4	0/0	(3)	0/0	0/0						
Hexahydropyridine	-> see: Piperidine	—	—	—	—																														
Hexaldehyde, n-	C ₆ H ₁₂ O	000066-25-1	—	F, Xi	X	0/0	0/0	0/0	(4)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	4/4	4/4	0/0	(1)	(1)	(1)						
Hexamethylenetetramine	C ₆ H ₁₂ N ₄	000100-97-0	—	F, Xn	X	0/0	0/0	(2)	(2)	1/0	0/0	(2)	(2)	1/1	0/0	0/0	0/0	1/1	0/0	(1)	(1)	(2)	(2)	(2)	(3)	0/0	(1)	1/1	1/1	0/0	Methenamine; Hexamine; Urotropin				
Hexane, n-	C ₆ H ₁₄	000110-54-3	—	F, Xn	X	2/3	4/4	1/0	(2)	1/0	3/4	1/1	2/3	4/4	1/2	2/4	4/4	1/1	1/1	1/1	1/1	1/1	4/4	1/1	1/1	0/0	1/1	1/1	1/1	0/0					
Hexanedioic acid	-> see: Adipic acid	—	—	—	—																														
Hexanetriol	C ₆ H ₁₄ O ₃	—	100 %	?	—	1/1	1/1	(2)	(2)	(1)	0/0	(1)	1/1	1/0	0/0	1/1	3/3	1/1	0/0	(1)	1/1	(1)	1/0	1/0	1/0	0/0	(1)	(1)	(1)	0/0	isomer not indicated in the source				
Hexene, 1-	C ₆ H ₁₂	000592-41-6	—	F, Xn	X	0/0	0/0	1/0	(2)	(1)	(4)	(1)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	4/4	1/0	3/3	0/0	1/1	1/1	1/1		Butyl ethylene; Hexylene				
Hexyl alcohol	C ₆ H ₁₄ O	000111-27-3	—	Xn	—	1/0	1/0	(2)	(2)	(1)	0/0	(1)	1/2	0/0	3/0	1/0	3/0	1/3	0/0	(1)	1/0	(1)	4/4	1/0	1/0	0/0	(1)	(1)	1/1	0/0					
Honey	—	—	—	—	—	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	1/1	0/0	(1)	(1)	(1)	0/0						
Hydraulic fluids, HFA	—	—	50°C	?	—	0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	(1)	0	4	0	1	0	(2)	0	0							
Hydraulic fluids, HFB	—	—	50°C	?	—	0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	(1)	0	4	0	1	0	(2)	0	0							
Hydraulic fluids, HFC	—	—	60°C	?	—	0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	(1)	0	0	0	1	0	(2)	0	0							
Hydraulic fluids, HFD-R	—	—	100°C	?	—	0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	0	0	0	0	4	0	(2)	0	0							
Hydraulic fluids, HFD-S	—	—	100°C	?	—	0	0	0	0	0	0	(3)	0	0	0	0	0	0	0	0	0	0	0	4	0	(2)	0	0							
Hydraulic oil (based on mineral oil)	—	—	?	?	—	0/0	0/0	0/0	0/0	(1)	0/0	1/0	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	4/4	(1)	1/0	0/0	1/1	1/1	1/1						
Hydrazine	N ₂ H ₄	000302-01-2	10 %	T	X	1/1	1/0	4/4	(4)	0/0	0/0	2/0	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/0	1/0	1/3	1/0	3/4	4/4	0/0	1/0	1/3	1/3	1/1	Diamide; Diamine; Nitrogen hydride				
Hydrazine hydrate	N ₂ H ₄ O	010217-52-4	aqueous	(T, C)	(X)	1/1	1/0	4/4	(4)	0/0	0/0	2/0	1/1	0/0	0/0	1/0	0/0	0/0	0/0	1/0	1/0	1/3	1/0	3/4	4/4	0/0	1/0	1/3	1/3	0/0					
Hydrocyanic acid, sodium salt	-> see: Sodium cyanide	—	—	—	—																														
Hydrogen	H ₂	001333-74-0	techn. pure	F+	X	1/1	1/1	1/0	1/0	0/0	0/0		1/1	1/0	0/0	1/1	1/1	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/1	1/1	1/1					
Hydrogen bromide	HBr	010035-10-6	40 %	C	—	1/0	1/1	4/4	4/4	(4)	4/4	4/4	1/1	4/4	0/0	1/1	3/3	0/0	0/0	1/1	1/1	1/1	3/0	1/0	4/4	0/0	(4)	(4)	(4)	0/0					
Hydrogen bromide	HBr	010035-10-6	50 %	C	—	1/1	1/2	4/4	4/4	(4)	4/4	4/4	1/2	4/4	0/0	1/1	3/3	0/0	1/1	1/1	1/1	1/1	3/0	1/0	4/4	0/0	(4)	(4)	(4)	0/0					
Hydrogen bromide	HBr	010035-10-6	diluted	C	—	1/1	1/1	4/4	4/4	3/0	4/4	4/4	1/1	4/4	0/0	1/3	3/0	0/0	0/0	1/1	1/1	1/1	3/0	1/0	4/4	0/0	(4)	(4)	(4)	0/0					
Hydrogen carboxylic acid	-> see: Formic acid	—	—	—	—																														
Hydrogen chloride	HCl	007647-01-0	1-5 %	—	—	1/1	1/1	4/4	1/1	(2)	1/2	4/4	1/1	1/1	1/1	1/1	0/0	1/																	

CHEMICALS	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	thermoplastics										fluoroplastics		elastomers		metals				COMMENT								
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM		FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C	
Hydrogen sulfide	H ₂ S	007783-06-4	saturated	F+, T+	X	1/1	1/1	1/0	1/0	1/0	0/0	1/1	3/0	1/0	1/3	3/3	1/0	0/0	1/0	1/1	1/1	1/0	(3)	4/4	0/0	1/1	1/1	1/1	0/0			
Hydroquinone	C ₆ H ₂ O ₂	000123-31-9	saturated	Xn		0/0	1/3	4/4	(3)	1/0	0/0	(3)	1/0	4/4	0/0	1/0	0/0	1/3	0/0	(1)	1/1	(3)	4/4	4/4	4/4	0/0	(1)	1/0	1/0	0/0	Hydroquinol; Quinol	
Hydroxylaluminium di(acetate)	C ₄ H ₇ AlO ₅	000139-12-8	aqueous	Xn		1/1	1/1	1/1	(1)	1/0	1/1	1/0	1/1	0/0	0/0	1/3	1/3	0/0	1/1	1/1	1/1	(1)	1/0	(3)	3/0	0/0	1/1	1/1	1/1	0/0		
Hydroxylamine disulfate	H ₂ N ₂ SO ₆	010039-54-0	12 %	Xn		1/1	1/1	0/0	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	1/3	0/0	(4)	1/1	1/1	1/1	1/1		
Hydroxylamine disulfate	H ₂ N ₂ SO ₆	010039-54-0	each	Xn		1/1	0/0	0/0	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	1/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	1/3	0/0	(4)	1/1	1/1	1/1		
Hydroxymethyl furfural, 5- (HMF)	C ₆ H ₆ O ₃	000067-47-0		Xi		0/0	0/0	(3)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	(3)	(3)	4/4	0/0	(1)	(1)	(1)			
Imidole	-> see: Pyrrole																															
Iodine pentafluoride	IF ₅	007783-66-6		(T, C)		0/0	0/0	4/4	(4)	(4)	0/0	4/4	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(2)	(3)	4/4	4/4	4/4	4/4	0/0	(3)	0/0	0/0		
Iodine, tincture of	I ₂	007553-56-2		Xn	(X)	1/3	1/3	4/4	3/4	0/0	1/1	1/1	1/2	3/3	0/0	4/4	4/4	3/3	1/1	0/0	1/1	1/1	2/0	1/1	3/3	0/0	1/0	2/0L	1/0L	1/1		
Iodoform	CHI ₃	000075-47-8	100 %	Xn		3/0	3/0	(3)	3/0	0/0	0/0	(2)	3/0	3/0	0/0	4/4	4/4	0/0	0/0	(1)	1/0	(2)	1/0	1/0	(3)	0/0	(3)	(1)	(1)	1/1	Triiodomethane;	
Isoamyl alcohol	C ₅ H ₁₂ O	000123-51-3		Xn	X	0/0	0/0	(2)	3/0	1/0	0/0	1/0	1/1	1/3	0/0	0/0	0/0	1/3	0/0	(1)	1/1	1/1	3/0	2/4	3/3	0/0	(1)	(1)	(1)			
Isobutanol	C ₄ H ₁₀ O	000078-83-1		Xn	X	1/1	1/1	(2)	1/2	(2)	1/2	1/0	1/1	2/2	1/2	1/2	0/0	3/4	1/1	1/1	(1)	1/1	1/0	1/0	3/4	0/0	1/0	(1)	(1)	0/0	Methyl-1-propanol, 2-; Isopropyl carbinol; Isobutyl alcohol	
Isobutyl acetate	C ₆ H ₁₂ O ₂	000110-19-0		F	X	0/0	0/0	(2)	(4)	0/0	(4)	1/0	(3)	4/4	0/0	3/0	4/4	0/0	0/0	(1)	1/0	(2)	2/0	4/4	4/4	0/0	(1)	(1)	(1)	0	Methylpropyl acetate, 2-; Methylpropyl ethanoate, Beta-	
Isobutyl alcohol	-> see: Isobutanol																															
Isobutyltrimethylmethane	-> see: Trimethylpentane, 2,2,4-																															
ISO-Fluid	—	—	liquid	Xn, N	X	0/0	2/3	(1)	(3)	1/0	(4)	1/0	3/4	4/4	0/0	1/3	0/0	1/3	0/0	(1)	1/1	(1)	4/4	1/1	1/0	0/0	1/1	1/1	1/1	0/0		
ISO-Fluid A	—	—		(Xn, N)	(X)	0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	0/0	1/0	0/0	(1)	(1)	(1)			
ISO-Fluid B	—	—		(Xn, N)	(X)	0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	0/0	3/0	0/0	(1)	(1)	(1)			
ISO-Fluid C	—	—		(Xn, N)	(X)	0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	0/0	3/0	0/0	(1)	(1)	(1)			
ISO-Fluid D	—	—		(Xn, N)	(X)	0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	0/0	4/4	0/0	(1)	(1)	(1)			
Iso-octane	-> see: Trimethylpentane, 2,2,4-																															
Isopropyl acetate	C ₅ H ₁₀ O ₂	000108-21-4		F, Xi	X	1/2	2/3	1/0	4/4	(3)	2/3	1/0	2/3	4/4	4/4	4/4	4/4	0/0	1/2	1/1	1/1	(3)	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0		
Isopropyl alcohol	C ₃ H ₈ O	000067-63-0	techn. pure	F	X	1/1	1/1	1/0	1/2	1/0	1/2	1/0	1/1	2/2	1/2	1/2	4/4	1/4	1/1	1/1	1/1	1/1	1/0	1/1	3/3	0/0	(2)	(1)	(1)	0/0		
Isopropyl carbinol	-> see: Isobutanol																															
Isopropyl chloride	C ₃ H ₇ Cl	000075-29-6		F, Xn	X	0/0	0/0	(2)	(4)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	4/4	0/0	(3)	0/0	0/0			
Jam	—	—		—		1/1	1/1	(1)	1/1	1/1	0/0	(2)	1/1	1/1	0/0	1/3	0/0	1/1	1/1	1/1	1/1	1/1	(2)	(1)	(1)	0/0	(2)	1/1	1/1	1/1		
Juices	—	—		—		1/1	1/1	1/0	1/0	1/0	1/0	1/1	1/1	0/0	0/0	1/1	1/1	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	(2)	1/1	1/1	1/1	1/1		
Kapsolat	-> see: Ethylene glycol monomethyl ether oleate																															
Kerosene	—	008008-20-6		(Xn)		2/2	3/4	(1)	4/4	1/1	2/3	1/1	3/3	4/4	2/3	1/1	0/0	0/0	2/3	1/1	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0	lamp oil	
Kerosene	—	—	techn. pure	Xn, N	X	1/3	3/4	1/0	3/0	(1)	0/0	1/1	1/3	4/4	1/0	1/0	3/0	3/4	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	1/1	1/1	1/1	1/1		
Lactames	—	—		?		0/0	0/0	0/0	0/0	0/0	0/0	(2)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	4/4	4/4	4/4	0/0	(2)	(1)	(1)			cyclic amides	
Lactic acid	C ₃ H ₆ O ₃	000050-21-5	3 %	?		1/1	1/2	(3)	1/2	1/0	1/2	2/4	1/2	2/2	1/1	2/3	0/0	1/1	1/1	1/1	1/1	1/1	3/4	1/1	(2)	0/0	(1)	1/1	1/1	1/1	lactol	
Lactic acid	C ₃ H ₆ O ₃	000050-21-5	80 %	C		1/1	1/1	3/4	1/2	0/0	1/2	3/4	1/1	1/1	1/1	2/3	2/3	1/1	1/2	1/1	1/1	1/3	3/4	1/1	1/4	0/0	1/0	1/3	1/2	1/1	lactol	
Lactic acid	C ₃ H ₆ O ₃	000050-21-5	85 %	C		1/1	1/1	3/4	1/2	0/0	1/2	3/4	1/2	2/2	1/1	2/3	2/3	1/1	1/2	1/1	1/1	1/3	3/4	1/1	1/4	0/0	1/0	1/3	1/2	1/1	lactol	
Lactose	C ₁₂ H ₂₂ O ₁₁	000063-42-3	aqueous	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(1)	1/1	1/1	0/0		
Lanolin	—	008006-54-0	techn. pure	—		3/3	3/3	1/0	1/0	0/0	(2)	3/3	1/1	0/0	3/3	3/3	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/1	0/0	(1)	1/1	1/1	1/1	1/1		
Lard	—	—		—		0/0	0/0	(2)	(1)	1/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	2/0	1/0	1/0	0/0	(1)	1/1	1/1			
Latex	—	—		?		0/0	0/0	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(3)	(1)	(2)	0/0	(2)	(1)	(1)	1/1	dispersion of rubber	
Laurel	—	—	ground	?		0/0	0/0	(2)	(2)	(2)	0/0	(2)	(2)	1/1	0/0	0/0	0/0	1/1	0/0	(1)	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)			
Lauryl alcohol	C ₁₂ H ₂₆ O	000112-53-8	100 %	Xi		0/0	0/0	(2)	(2)	1/0	0/0	(2)	1/1	1/1	0/0	1/1	0/0	1/1	0/0	(1)	1/1	1/1	3/0	1/0	3/3	0/0	(1)	(1)	(1)	0/0		
Lauryl chloride	C ₁₂ H ₂₅ Cl	000112-52-7	100 %	(Xi)		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	(1)	4/4	(1)	(							

CHEMICALS	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	thermoplastics										fluoroplastics		elastomers		metals				COMMENT							
						HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTE	PVDF	EPDM		FPM / FKM	NBR	SI	AL	V2A	V4A	Hasstloy C
Magnesium bromide	MgBr ₂	007789-48-2		Xi		1/1	1/1	(2)	(2)	0/0	1/1	1/1	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(2)	0/0	(3)	0/0	0/0					
Magnesium carbonate	MgCO ₃	000546-93-0	saturated	—		1/1	1/1	1/0	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1		
Magnesium chloride	MgCl ₂	007786-30-3	aqueous	Xi		1/1	1/1	1/0	1/0	1/0	1/2	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/1	1/0L	1/0L	1/1			
Magnesium chlorite	Mg(ClO ₂) ₂	??		O		0/0	0/0	0/0	0/0	0/0	0/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0		
Magnesium hydroxide	Mg(OH) ₂	001309-42-8	saturated	—		1/1	1/1	1/0	(2)	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	2/0	1/1	1/1	1/1	1/1	1/1	0/0			
Magnesium iodide	MgJ ₂	010377-58-9		(Xn)		1/1	1/1	(2)	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	1/1	(1)	(2)	0/0	(2)	0/0	0/0			
Magnesium nitrate	Mg(NO ₃) ₂	010377-60-3	saturated	O, Xi		1/1	1/1	1/0	(2)	(1)	1/0	1/1	1/1	1/0	0/0	1/1	1/0	0/0	1/1	1/1	1/1	(1)	(2)	0/0	1/0	1/0	1/0	1/1		Nitric acid, magnesium salt;	
Magnesiumsulfat	MgSO ₄	007487-88-9	each	—		1/1	1/1	1/0	1/0	1/0	1/0	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	2/0	0/0	1/1	1/1	1/1	1/1	1/1		
Maize-germ oil	—	008001-30-7	techn. pure	—		1/3	0/0	(2)	(1)	1/0	0/0	(2)	1/3	1/1	0/0	3/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/1	1/0	0/0	(1)	1/1	1/1	1/1	corn oil
Maleic acid	C ₄ H ₂ O ₄	000110-16-7	saturated	Xn		1/1	1/1	4/4	(3)	0/0	0/0	(3)	1/1	0/0	0/0	1/3	1/0	0/0	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	1/1	1/1	1/1	1/1	
Maleic acid	C ₄ H ₂ O ₄	000110-16-7	aqueous	Xn		1/1	1/1	4/4	(3)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	4/4	1/1	1/0	0/0	1/1	1/1	1/1	1/1	1/1	
Margarine	—	—		—		0/0	0/0	(2)	1/0	1/0	0/0	(2)	1/1	1/0	0/0	0/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	(1)	1/1	1/1		
Menthol	C ₁₀ H ₂₀ O	000089-78-1	solid	Xi		1/3	3/4	3/0	3/4	0/0	0/0	(2)	1/3	4/4	0/0	0/0	0/0	0/0	(1)	1/1	1/1	3/0	1/0	3/3	0/0	(1)	1/0	1/0			
Mercuric chloride	HgCl ₂	007487-94-7	aqueous	T+, C		1/1	1/1	4/4	1/0	(2)	1/1	3/0	1/1	1/3	1/0	1/3	1/0	1/1	1/1	1/1	1/1	1/0	1/1	1/3	0/0	4/4	(4)	(4)	1/1		
Mercuric cyanide	C ₂ HgN ₂	000592-04-1	saturated	T+		1/1	1/1	(3)	(2)	(0)	(3)	1/1	0/0	0/0	1/3	0/0	0/0	(1)	1/1	1/1	1/1	(1)	1/1	(2)	0/0	4/4	1/0	1/0	1/1		
Mercuric nitrate	Hg(NO ₃) ₂	010045-94-0	saturated	(T+)		1/1	1/1	1/0	(2)	(2)	0/0	(3)	1/1	1/0	0/0	1/3	1/0	0/0	(1)	1/1	1/1	1/1	1/0	1/1	1/3	0/0	4/4	1/1	1/1	1/1	
Mercury	Hg	007439-97-6	pure	T		1/1	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	3/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(3)	1/1	1/1	1/1			
Mesityl oxide	C ₉ H ₁₀ O	000141-79-7		Xn	X	0/0	0/0	(2)	(4)	(4)	(4)	(2)	(3)	4/4	0/0	0/0	0/0	4/4	0/0	(1)	1/1	0/0	3/0	4/4	4/4	0/0	(1)	(1)	(1)		
Methacetone	-> see: Pentanone, 3-																														
Methacrylic acid	C ₄ H ₆ O ₂	000079-41-4		C		1/0	1/1	4/4	4/4	0/0	0/0	4/4	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(3)	3/0	4/4	4/4	0/0	(4)	0/0	0/0			
Methane	CH ₄	000074-82-8	techn. pure	F+	X	1/0	0/0	1/0	1/0	1/0	0/0	1/0	1/0	0/0	0/0	1/0	0/0	0/0	0/0	1/1	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0	
Methanoic acid	-> see: Formic acid																														
Methenamine	-> see: Hexamethylenetetramine																														
Methoxy butanol	C ₃ H ₇ O ₂	—	100 %	?	X	0/0	1/3	(2)	(3)	0/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	3/0	1/0	1/0	0/0	(1)	(1)	(1)		isomer not indicated in the source	
Methoxyethane	C ₃ H ₈ O	000540-67-0	100 %	(F+)	X	0/0	3/0	(1)	(4)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	(1)	1/0	(2)	4/4	4/4	4/4	0/0	1/1	(1)	(1)		Methyl ethyl ether;	
Methoxyethyl oleate	-> see: Ethylene glycol monomethyl ether oleate																														
Methyl acetate	C ₃ H ₆ O ₂	000079-20-9	techn. pure	F	X	1/0	1/1	1/0	4/4	3/0	(4)	2/0	1/3	4/4	0/0	4/4	4/4	4/4	0/0	1/0	1/1	1/4	3/0	4/4	4/4	0/0	(1)	1/1	1/1	0/0	
Methyl acrylate	C ₅ H ₈ O ₂	000096-33-3		F, Xn	X	0/0	0/0	(2)	4/4	(4)	(4)	(2)	(2)	4/4	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	4/4	4/4	0/0	(1)	(1)	(1)			
Methyl alcohol	CH ₃ O	000067-56-1		F, T	X	1/1	1/1	2/0	4/4	1/0	1/1	1/1	1/1	3/4	3/3	1/3	3/4	1/1	1/1	1/1	1/1	1/0	3/4	3/3	0/0	1/0	1/1	1/1			
Methyl amine	CH ₃ N	000074-89-5	32 %	F+, C	X	1/0	1/0	4/4	4/4	0/0	0/0	1/0	1/0	0/0	0/0	3/0	4/4	0/0	0/0	(1)	1/0	3/0	1/0	4/4	4/4	0/0	1/0	1/0	1/0	0/0	
Methyl benzene	C ₆ H ₆	000108-88-3		F, Xn	X	3/4	3/4	1/0	4/4	1/0	3/3	1/3	4/4	4/4	4/4	4/4	4/4	1/1	1/1	1/0	1/1	4/4	3/3	4/4	0/0	1/1	1/1	1/1	1/1		
Methyl bromide	CH ₃ Br	000074-83-9	techn. pure	T		3/0	4/4	1/0	(3)	0/0	0/0	1/0	4/4	4/4	0/0	4/4	4/4	0/0	1/0	1/0	1/1	4/4	1/0	4/4	0/0	4/4	1/1L	1/1L	0/0		
Methyl butanol	C ₅ H ₁₂ O	—		Xn	X	0/0	0/0	(2)	(2)	1/0	0/0	1/0	1/0	0/0	0/0	0/0	1/3	0/0	(1)	1/1	1/1	3/0	2/2	3/3	0/0	(1)	(1)	(1)		isomer not indicated in the source	
Methyl butyl ketone	C ₈ H ₁₆ O	000591-78-6		F, T	X	0/0	0/0	(2)	(4)	(4)	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	(1)	(1)	(3)	1/0	4/4	4/4	0/0	(1)	(1)	(1)			
Methyl cellosolveat oleate	-> see: Ethylene glycol monomethyl ether oleate																														
Methyl chloride	CH ₃ Cl	000074-87-3	techn. pure	F+, T	X	3/0	2/0	4/4	(3)	0/0	0/0	1/0	4/4	4/4	4/4	4/4	4/4	0/0	1/0	1/0	1/1	4/4	4/4	4/4	0/0	4/4	1/1L	1/1L			
Methyl cyanide	-> see: Acetonitrile																														
Methyl dichloroacetate	C ₂ H ₃ Cl ₂ O ₂	000116-54-1		(Xn)		1/1	0/0	(3)	(4)		(4)	(3)	1/1	0/0	0/0	4/4	0/0	0/0	(1)	1/1	3/3	4/4	4/4	4/4	0/0	(3)	0/0	0/0			
Methyl ethyl carbinol	-> see: Butyl alcohol, sec-																														
Methyl ethyl ether	-> see: Methoxyethane																														
Methyl ethyl ketone (MEK)	C ₆ H ₁₀ O	000078-93-3		F	X	1/3	3/4	1/0	4/4	4/4	4/4	1/2	1/3	4/4	4/4	4/4	4/4	2/3	1/1	1/1	3/4	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0		
Methyl ethylene oxide	-> see: Propylene oxid																														

CHEMICALS	thermoplastics																												fluoroplastics		elastomers		metals			
	FORMULA	CAS-NR	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C	COMMENT					
Molasses	—	—	—	—	—	1/1	1/1	1/0	(1)	1/0	0/0	2/0	1/1	0/0	0/0	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/0	1/1	0/0	(2)	(1)	1)						
Molasses wort	—	—	—	?	—	1/1	1/1	1/0	(2)	(2)	0/0	2/0	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	(2)	(1)	1)							
Monochlorobenzene (MCB)	-> see: Chlorobenzene																																			
Monochloroethane	C ₂ H ₅ Cl	000075-00-3	—	F+, Xn	X	3/3	3/4	1/0	4/4	0/0	3/4	1/0	3/4	4/4	4/4	4/4	4/4	4/4	1/1	1/1	1/0	1/1	4/4	3/0	4/4	0/0	(3)	1/1L	1/1L	0/0	Ethyl chloride; Chloroethane, 1-					
Morpholine	C ₄ H ₉ NO	000110-91-8	techn. pure	C, Xn	X	1/1	1/1	(3)	(3)	0/0	0/0	(2)	1/1	0/0	0/0	4/4	4/4	0/0	0/0	(1)	1/1	1/3	3/0	2/3	4/4	0/0	1/0	(1)	(1)	0/0						
Motor oil	—	—	—	?	—	0/0	0/0	1/0	(2)	(1)	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0						
Mowilith D	—	—	—	?	—	1/0	0/0	(2)	0/0	(2)	0/0	(2)	1/0	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/0	(2)	(2)	(2)	0/0	(2)	(1)	(1)	0/0	dispersion of polyvinyl acetate; Clariant					
Muscat	—	—	ground	?	—	0/0	0/0	(2)	4/4	(2)	0/0	(2)	2)	4/4	0/0	0/0	0/0	3/3	0/0	(1)	(1)	(2)	(2)	(2)	(2)	0/0	(1)	(1)	0/0							
Mustard	—	—	—	—	—	0/0	0/0	(2)	1/0	(1)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	1/1	0/0	1/1	(1)	(1)	(2)	1/0	1/0	0/0	(2)	1/0L	1/0L	0/0						
Naphtha	—	008032-32-4	—	(Xn)	—	1/3	3/4	1/0	(2)	(1)	1/0	1/0	1/3	3/0	1/0	1/0	4/4	0/0	0/0	(1)	1/1	1/1	4/4	1/1	4/4	0/0	1/1	1/1	1/1	0/0	petroleum ether					
Naphthalene	C ₁₀ H ₈	000091-20-3	100 %	F, Xn	X	0/0	1/3	1/0	(3)	0/0	0/0	1/2	1/3	3/4	1/0	4/4	4/4	1/4	0/0	(1)	1/1	1/3	4/4	1/1	4/4	0/0	1/1	1/1	1/1	0/0						
Naphthalene (in alcohol)	—	—	—	F, Xn	X	1/4	1/4	(2)	(3)	0/0	0/0	1/2	1/3	3/4	0/0	0/0	0/0	3/4	0/0	(1)	1/1	(2)	4/4	(3)	(3)	0/0	(1)	(1)	(1)	0/0						
Neon	Ne	007440-01-9	—	—	—	0/0	0/0	1/0	(1)	1/1	0/0	1/1	(1)	0/0	0/0	0/0	0/0	0/0	1/1	(1)	1/1	1/1	1/1	1/1	1/0	0/0	1/1	1/1	1/1	0/0						
Nickel acetate	C ₂ H ₄ NiO ₄	000373-02-4	aqueous	(T, N)	—	1/1	1/1	(3)	(2)	(1)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	(3)	3/0	0/0	4/4	0/0	0/0	0/0						
Nickel dichloride	NiCl ₂	007718-54-9	saturated	T	—	1/1	1/1	1/0	(2)	(1)	0/0	2/0	1/1	0/0	0/0	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	4/4	2/0L	2/0L	1/1						
Nickel dichloride	NiCl ₂	007718-54-9	aqueous	T	—	1/1	1/1	(3)	(2)	(1)	0/0	2/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	4/4	2/0L	2/0L	1/1						
Nickel sulfate	NiSO ₄	007786-81-4	saturated	Xn	—	1/1	1/1	1/0	1/0	(1)	1/0	2/0	1/1	1/1	0/0	0/0	1/1	1/3	1/1	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	4/4	1/1	1/1	1/1					
Nickel sulfate	NiSO ₄	007786-81-4	aqueous	Xn	—	1/1	1/1	(3)	1/0	(1)	0/0	2/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	4/4	1/1	1/1	1/1						
Nickelous nitrate	Ni(NO ₃) ₂	013138-45-9	saturated	(O, Xn)	—	1/1	1/1	(3)	(2)	(1)	1/0	(2)	1/1	1/0	1/0	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	4/4	1/0	1/0	1/1						
Nicotine	C ₁₀ H ₁₄ N ₂	000054-11-5	—	T+	—	1/0	1/0	(3)	(3)	0/0	0/0	(2)	1/0	1/0	0/0	1/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	1/1	0/0	(1)	(1)	(1)	0/0						
Nicotinic acid	C ₆ H ₅ NO ₂	000059-67-6	diluted	Xi	—	1/1	1/1	(3)	(2)	0/0	0/0	(3)	1/0	0/0	0/0	1/1	0/0	0/0	0/0	1/1	(1)	(2)	(2)	(3)	(2)	0/0	(3)	0/0	0/0	0/0						
Nitric acid	HNO ₃	007697-37-2	1-10 %	C	—	1/1	1/1	4/4	1/2	(2)	1/1	4/4	1/1	2/4	1/3	1/2	0/0	1/3	1/1	1/1	1/1	1/1	2/0	1/1	4/4	0/0	3/4	1/1	1/1	1/1						
Nitric acid	HNO ₃	007697-37-2	50 %	C+	—	2/4	3/4	4/4	4/4	(2)	2/4	4/4	3/4	4/4	2/3	2/3	0/0	0/3	1/1	1/1	1/1	1/1	4/4	1/0	4/4	0/0	4/4	1/2	1/2	1/2	1/2					
Nitric acid	HNO ₃	007697-37-2	66 %	C+	—	2/4	3/4	4/4	4/4	(4)	2/3	4/4	4/4	4/4	4/4	3/4	0/0	0/0	1/1	1/1	1/1	1/1	4/4	1/0	4/4	0/0	4/4	1/2	1/2	1/2	1/2					
Nitric acid	HNO ₃	007697-37-2	100 %	O, C+	—	4/4	4/4	4/4	4/4	(4)	0/0	4/4	4/4	0/0	0/0	4/4	0/0	4/4	0/0	0/0	1/1	4/4	4/4	4/4	4/4	0/0	1/1	2/3	3/3	?	?					
Nitric acid	HNO ₃	007697-37-2	70 %	O, C+	—	2/4	3/4	4/4	4/4	(4)	2/3	4/4	4/4	4/4	4/4	3/4	0/0	0/0	1/1	1/1	1/1	1/1	4/4	2/3	4/4	0/0	4/4	1/2	1/2	1/2	1/2					
Nitric acid	-> see: Ammonium nitrate																																			
Nitric acid, magnesium salt	-> see: Magnesium nitrate																																			
Nitric acid, potassium salt	-> see: Potassium nitrate																																			
Nitro benzoic acid	C ₇ H ₅ NO ₄	—	—	(Xn)	—	1/0	1/0	(3)	(3)	0/0	0/0	(3)	1/0	0/0	0/0	1/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	(3)	(2)	0/0	(3)	0/0	0/0	0/0	isomer not indicated in the source					
Nitro reducer	—	—	—	?	X	0/0	0/0	3/0	(4)	0/0	(4)	(3)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	(3)	(4)	4/4	0/0	(1)	(1)	(1)	1/1	1/1	solvent cleaner mixture				
Nitrobenzene	C ₆ H ₅ NO ₂	000098-95-3	—	T	—	3/4	4/4	4/4	4/4	1/0	4/4	3/0	2/4	4/4	4/4	4/4	4/4	4/4	1/2	1/1	1/1	1/1	4/4	4/4	4/4	0/0	(1)	1/1	1/1	1/1	1/1					
Nitroethane	C ₂ H ₅ NO ₂	000079-24-3	—	Xn	X	0/0	0/0	(3)	(4)	0/0	0/0	(3)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0	0/0					
Nitrogen	N ₂	007727-37-9	—	—	—	0/0	0/0	1/0	1/1	1/1	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1					
Nitrogen hydride	-> see: Hydrazine																																			
Nitrogen tetroxide	N ₂ O ₄	010544-72-6	—	(O), T+, C	—	0/0	0/0	3/0	(3)	1/0	0/0	4/4	1/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	4/4	4/4	0/0	(2)	(1)	(1)	0/0	0/0					
Nitroglycerine	C ₃ H ₅ (NO ₃) ₃	000055-63-0	diluted	(E, T+)	—	0/0	0/0	(3)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	3/0	4/4	0/0	0/0	(1)	1/0	(3)	1/0	1/0	4/4	0/0	0/0	0/0	0/0	0/0	0/0					
Nitrohydrochloric acid	HNO ₃ + HCl	008007-56-5	—	C	—	4/4	4/4	4/4	4/4	4/4	3/3	4/4	4/4	4/4	4/4	4/4	4/4	3/4	1/1	(2)	1/1	3/0	4/4	4/4	4/4	0/0	4/4	4/4	4/4	4/4	4/4					
Nitropropane	C ₃ H ₇ NO ₂	—	—	(T)	—	0/0	0/0	(3)	(4)	0/0	0/0	(3)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0	0/0					
Nitrose gases	—	—	diluted	T	—	1/1	0/0	3/0	4/4	0/0	0/0	4/4	1/4	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	3/0	3/0	4/4	0/0	(2)	(1)	(1)	0/0	nitrogen monoxide + nitrogen dioxide					
Nitrotoluene	C ₇ H ₇ NO ₂	001321-12-6	techn. pure	T	—	1/3	1/3	4/4	4/4	1/0	(4)	3/0	1/3	4/4	0/0	4/4	4/4	0/0	0/0	(1)	1/1	1/1	4/4	4/4	4/4	0/0	(1)	1/1	1/1	1/1	1/1					
Nitrous acid, sodium salt	-> see: Sodium nitrite																																			
Nitrous oxide	N ₂ O	010024-97-2	—	(O)	—	0/0	0/0	(2)	(2)	(1)	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	2/0	1/0	1/0	0/0	1/1	(1)	(1)	0/0	nitric oxide					
Nonanol</																																				

CHEMICALS	thermoplastics																												fluoroplastics		elastomers		metals				COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A								
Oxalic acid	C ₂ H ₂ O ₄ x 2H ₂ O	000144-62-7		Xn		1/1	1/1	3/4	1/0	0/0	1/1	4/4	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/3	1/0	1/1	3/3	0/0	1/0	2/3	1/3	1/3								
Oxygen	O ₂	007782-44-7	techn. pure	O		1/3	1/3	2/0	1/0	(1)	0/0	1/0	1/3	1/0	0/0	1/1	1/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	3/3	0/0	(2)	(1)	(1)	0/0							
Ozone	O ₃	010028-15-6		(O, T)		3/4	3/4	4/4	1/2	0/0	1/1	4/4	3/4	2/2	1/1	1/2	0/0	1/1	1/1	1/1	(1)	1/3	1/0	1/0	4/4	0/0	(2)	0/0	0/0	0/0							
Ozone-air-mixture	—	—		(O, T)		0/0	0/0	4/4	(2)	0/0	0/0	4/4	3/4	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(2)	1/0	1/0	4/4	0/0	(2)	0/0	0/0	0/0							
Palm kernel oil	—	008023-79-8		—		0/0	0/0	1/0	(2)	1/0	0/0	(2)	1/3	1/1	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	(1)	1/1	1/1	1/1							
Palm oil	—	008002-75-3		—		1/3	0/0	1/0	(2)	1/0	0/0	(2)	1/3	0/0	0/0	1/0	0/0	1/1	0/0	(1)	1/1	1/1	4/4	1/0	1/1	0/0	(1)	1/1	1/1								
Palmitic acid	C ₁₆ H ₃₂ O ₂	000057-10-3	techn. pure	Xi		3/3	2/2	1/1	(2)	1/0	0/0	1/0	3/4	1/1	0/0	1/1	3/0	1/1	0/0	(1)	1/1	1/1	4/4	1/1	3/3	0/0	1/1	1/1	1/1	1/1							
Paraffin wax	—	008002-74-2	melted	(—)		0	0	0	(2)	0	0	(2)	(2)	0	0	0	0	0	0	(1)	1	0	4	(2)	1	0	1	1	1								
Paraffin-emulsion	—	—		?		1/3	0/0	1/0	(2)	(2)	0/0	(2)	1/3	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	(4)	1/0	1/1	0/0	(2)	(1)	(1)	0/0							
Paraffins	C _n H _{2n+2}	—	100 %	?		1/0	1/1	1/0	1/0	1/0	1/1	1/1	1/0	1/0	1/0	1/0	0/0	0/0	0/0	(1)	1/1	(1)	4/4	1/0	1/3	0/0	1/1	1/1	1/1	1/1							
Paraformaldehyde	(CH ₂ O) _n ·H ₂ O	030525-89-4		F, T	X	0/0	0/0	0/0	(2)	1/0	0/0	(2)	1/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	1/0	3/3	0/0	(1)	(1)	(1)								
Peanut oil	—	008002-03-7		—		0/0	0/0	0/0	(2)	1/0	0/0	(2)	1/1	1/1	0/0	0/0	0/0	1/1	0/0	(1)	1/1	(1)	4/4	1/0	1/0	0/0	(1)	(1)	(1)	0/0							
Pectin	—	009000-69-5	aqueous	—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1								
Pectin	—	009000-69-5		—		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1								
Pelargonic alcohol	-> see: Nonyl alcohol	—																																			
Penicillin	—	—		Xn		(1)	(1)	(2)	(1)	(1)	0/0	(1)	(2)	0/0	0/0	0/0	0/0	1/1	(1)	1/1	(1)	(1)	(2)	(1)	(2)	0/0	(1)	(1)	(1)	antibiotic							
Pentachlorobiphenyl	C ₁₂ H ₅ Cl ₅	—		Xn		0/0	0/0	1/0	(3)	0/0	0/0	(2)	4/4	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	4/4	3/0	4/4	0/0	(1)	0/0	0/0								
Pentamethyleneimine	-> see: Piperidine	—																																			
Pentane, normal	C ₅ H ₁₂	000109-66-0		F	X	1/3	1/3	1/0	1/0	1/1	(3)	1/0	(3)	3/0	0/0	0/0	0/0	1/0	0/0	(1)	(1)	(1)	4/4	1/0	1/2	0/0	1/1	1/1	1/1								
Pentanethiol, 1-	C ₅ H ₁₂ S	000110-66-7		Xn	X	0/0	0/0	(2)	(3)	0/0	(4)	(2)	(2)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	4/4	(3)	(4)	0/0	(2)	(1)	(1)								
Pentanol, 1-	C ₅ H ₁₂ O	000071-41-0		Xn	X	1/1	1/2	1/0	1/0	1/0	2/3	1/0	1/1	1/3	3/0	2/3	3/0	0/4	1/1	1/1	1/1	1/1	3/0	2/4	3/0	0/0	1/2	1/1	1/1	0/0							
Pentanone, 3-	C ₅ H ₁₀ O	000096-22-0		F		2/2	2/3	(3)	4/4	(4)	2/3	1/0	2/2	4/4	4/4	0/0	4/4	2/3	1/1	1/1	(3)	(3)	(4)	(4)	0/0	(1)	(1)	(1)	0/0								
Pentyl alcohol, n-	-> see: Pentanol, 1-	—																																			
Pepper	—	—	ground	?		0/0	0/0	(2)	1/0	(1)	0/0	(2)	(2)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(2)	(2)	(2)	0/0	(1)	(1)	(1)								
Perchloric acid	HClO ₄	007601-90-3	70 %	E, O, C+		2/4	3/4	4/4	4/4	(4)	2/4	4/4	4/4	2/3	4/4	3/4	4/4	0/0	1/2	1/1	1/1	1/1	3/0	1/1	4/4	0/0	4/4	0/0	0/0	?							
Perchloric acid	HClO ₄	007601-90-3	20 %	Xi		0/0	1/3	4/4	3/0	0/0	0/0	4/4	1/3	0/0	0/0	1/3	3/0	0/0	0/0	1/1	1/1	1/1	2/0	1/1	4/4	0/0	4/4	0/0	0/0	1/1							
Perchlorobutadiene	C ₄ Cl ₆	000087-68-3		T		0/0	0/0	(3)	4/4	0/0	(4)	1/0	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(2)	(3)	4/4	1/0	4/4	0/0	(3)	0/0	0/0								
Perchloroethylene	-> see: Tetrachloroethylene	—																																			
Perfluorocyclobutane	C ₄ F ₈	000115-25-3		?		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	3/0	1/0	0/0	(3)	0/0	0/0								
Perfumes	—	—		?		3/0	3/0	1/0	(3)	1/0	0/0	(2)	1/0	4/4	0/0	1/0	3/0	0/0	0/0	(1)	(1)	(1)	(3)	(2)	(3)	0/0	(1)	(1)	(1)								
Permanganic acid, potassium salt	-> see: Potassium permanganate	—																																			
Petroleum	—	008002-05-9		(Xn)		0/0	0/0	1/0	(3)	1/0	0/0	1/0	1/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	1/1	4/4	1/0	3/3	0/0	(1)	(1)	(1)	0/0							
Petroleum ether	—	008032-32-4	techn. pure	(F, Xn)	X	1/3	1/3	1/0	3/0	1/0	1/1	1/3	4/4	1/0	1/1	3/3	3/3	0/0	(1)	1/1	1/1	4/4	1/0	1/3	0/0	1/1	1/1	1/1	1/1								
Phenacetin	C ₁₀ H ₁₃ NO ₂	000062-44-2		Xn		0/0	0/0	0/0	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(2)	(2)	(2)	0/0	(2)	(1)	(1)							
Phenethyl alcohol	C ₈ H ₁₀ O	000060-12-8		Xn		0/0	0/0	3/0	4/4	0/0	0/0	(2)	1/0	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(2)	(3)	(2)	4/4	0/0	(1)	(1)	(1)								
Phenetole	-> see: Ethoxybenzene	—																																			
Phenol	C ₆ H ₆ O	000108-95-2	10 %	T		1/1	1/1	4/4	4/4	4/4	1/0	4/4	1/1	4/4	4/4	1/3	3/3	3/3	0/0	1/0	1/1	1/1	4/4	2/3	4/4	0/0	1/1	1/2	1/1	0/0							
Phenol	C ₆ H ₆ O	000108-95-2	100 %	T, C		2/3	3/3	4/4	4/4	4/4	1/1	4/4	1/2	4/4	3/3	4/4	3/0	4/4	1/1	1/1	1/1	1/1	4/4	3/0	4/4	0/0	1/1	1/2	1/1	0/0							
Phenolic resin mass	—	—		?		1/1	1/1	(3)	(3)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	(4)	(3)	(3)	0/0	(2)	(1)	(1)	0/0							
Phenyl chloride	-> see: Chlorobenzene	—																																			
Phenyl methyl ketone	-> see: Acetophenone	—																																			
Phenylethanone, 1-	-> see: Acetophenone	—																																			
Phenyldiazine	C ₆ H ₈ N ₂	000100-63-0	techn. pure	T		3/0	0/0	(3)	(3)	0/0	0/0	(2)	3/4	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/3	4/4	0/0	(2)	0/0	0/0	0/0							
Phenyldiazine hydrochloride	C ₆ H ₈ N ₂ ·HCl	000059-88-1		T		0/0	0/0	(3)	(2)	0/0	0/0																										

CHEMICALS	thermoplastics																											fluoroplastics		elastomers		metals			
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C	COMMENT				
Pineapple juice	—	—	—	—	—	1/1	1/1	1/0	(2)	1/0	0/0	(2)	1/1	1/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	(2)	(1)	0/0	(2)	(1)	(1)							
Pink	—	—	ground	?	—	0/0	0/0	(2)	4/4	(1)	0/0	(2)	(2)	4/4	0/0	0/0	0/0	4/4	0/0	(1)	1/1	(2)	(2)	(2)	(2)	0/0	(1)	(1)	(1)		0/0				
Piperidine	C ₄ H ₁₁ N	000110-89-4	—	F, T, C	—	0/0	0/0	(3)	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)			Hexahydropyridine; Azacyclohexane; Pentamethyleimine			
Plasticiser	—	—	—	?	—	1/3	1/3	(2)	(3)	0/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	3/3	0/0	(1)	(1)	0/0	(2-3)	0/0	4/4	0/0	(1)	(1)	(1)						
Polish remover	—	—	—	?	(X)	0/0	0/0	(2)	4/4	0/0	(4)	(2)	1/3	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(3)	(3)	4/4	0/0	(1)	(1)	(1)		0/0				
Polyester resins	—	—	—	(Xn)	(X)	3/4	3/4	1/0	4/4	1/0	0/0	(2)	3/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	(3)	4/4	0/0	(1)	(1)	(1)							
Polyethylene glycol	HO-(C ₂ H ₄ O) _n -H	025322-68-3	100 %	(—)	—	1/1	1/1	(3)	0/0	0/0	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	(2-3)	(2)	(3)	0/0	(1)	(1)	(1)		0/0				
Polyoxymethylene	-> see: Paraformaldehyde	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—	—				
Polyran M25 N	—	—	80°C	?	—	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0/0	0	0	0/0	0	3	0	0	(1)	(1)			lubricating oil			
Polyran M400	—	—	80°C	?	—	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0/0	0	0	0/0	0	(3)	0	0	(1)	(1)			lubricating oil			
Polysolvan O	C ₆ H ₁₂ O ₃	007397-62-8	100 %	Xi	—	0/0	1/1	(2)	(3)	1/0	0/0	1/0	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	0/0	0/0	0/0	(3)	0/0	(1)	(1)	(1)			solvent cleaner, butyl glycolate; Celanese AG			
Potassium acetate	C ₂ H ₃ KO ₂	000127-08-2	aqueous	Xi	1/1	1/1	1/0	(1)	(2)	0/0	1/1	1/1	0/0	0/0	1/0	1/0	0/0	1/1	1/1	1/0	1/1	1/1	3/0	3/3	0/0	1/3	1/1	1/1	0/0						
Potassium bisulfate	KHSO ₄	007646-93-7	aqueous	(C)	1/1	1/1	4/4	1/0	(2)	0/0	2/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/0	4/4	4/4	1/1						
Potassium bisulfate	KHSO ₄	007646-93-7	—	C	1/1	1/1	4/4	1/0	0/0	0/0	2/0	1/1	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/0	4/4	4/4	?						
Potassium bitartrate	C ₄ H ₄ KO ₆	000868-14-4	saturated	Xi	1/1	1/1	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	1/0	1/0	0/0	1/1	1/1	1/1	1/1	(2)	(1)	(1)	0/0	(4)	1/3	1/2	0/0						
Potassium borate	KBO ₂	012228-88-5	10 %	(Xn)	1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	1/3	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/0	1/1	0/0	(3)	0/0	0/0	0/0					
Potassium borate	KBO ₂	012228-88-5	aqueous	(Xn)	1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/0	1/1	0/0	(3)	0/0	0/0	0/0					
Potassium bromate	KBrO ₃	007758-01-2	saturated	O, T	1/3	1/3	(2)	1/0	0/0	0/0	(2)	1/1	1/1	0/0	1/3	0/0	1/1	0/0	(1)	1/1	1/1	1/0	1/1	1/1	1/1	0/0	(2)	0/0	0/0	0/0					
Potassium bromate	KBrO ₃	007758-01-2	aqueous	O, T	0/0	0/0	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/1	0/0	(2)	0/0	0/0	0/0						
Potassium bromide	KBr	007758-02-3	each	Xn	1/1	1/1	3/0	1/0	(1)	1/0	1/1	1/1	1/1	0/0	1/3	1/0	1/1	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/0	1/0L	1/0L	1/1						
Potassium carbonate	K ₂ CO ₃	000584-08-7	saturated	Xn	1/1	1/1	1/1	3/3	(2)	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/3	1/0	1/0	1/1	0/0	4/4	1/1	1/1	1/1					
Potassium carbonate	K ₂ CO ₃	000584-08-7	aqueous	Xn	1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	4/4	1/1	1/1	1/1						
Potassium chlorate	KClO ₃	003811-04-9	saturated	O, Xn	1/1	0/0	1/0	(2)	0/0	0/0	2/0	1/1	1/0	0/0	1/1	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	4/4	0/0	1/1	1/1	1/1	1/1						
Potassium chlorate	KClO ₃	003811-04-9	aqueous	O, Xn	1/1	0/0	1/0	(2)	0/0	0/0	2/0	1/1	1/0	0/0	1/1	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	4/4	0/0	1/1	1/1	1/1	1/1						
Potassium chloride	KCl	007447-40-7	aqueous	Xi	1/1	1/1	1/0	1/0	1/0	1/0	1/1	1/1	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/3	1/1L	1/1L	1/1						
Potassium chromate	K ₂ CrO ₄	007789-00-6	saturated	T	1/0	1/1	2/0	(2)	0/0	1/0	(2)	1/1	1/1	0/0	1/1	1/0	1/1	0/0	(1)	1/1	1/1	1/0	1/0	3/3	0/0	1/1	(1)	(1)	1/1						
Potassium chromate	K ₂ CrO ₄	007789-00-6	aqueous	T	0/0	0/0	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	3/3	0/0	1/1	(1)	(1)	1/1						
Potassium cyanide	KCN	000151-50-8	saturated	T+	1/1	1/1	1/0	4/4	0/0	0/0	3/0	1/1	0/0	0/0	1/3	4/4	0/0	0/0	1/1	1/1	1/3	1/0	1/1	3/3	0/0	3/4	1/0	1/0	1/1						
Potassium cyanide	KCN	000151-50-8	aqueous	T+	1/1	1/1	1/0	4/4	0/0	0/0	3/0	1/1	0/0	0/0	1/3	1/4	0/0	0/0	1/1	1/1	1/3	1/0	1/1	3/3	0/0	3/4	1/0	1/0	1/1						
Potassium dichromate	K ₂ Cr ₂ O ₇	007778-50-9	saturated	T	1/1	1/0	4/4	3/0	3/0	1/0	3/0	1/1	1/3	0/0	1/3	1/0	1/3	0/0	(1)	1/1	1/1	1/0	2/0	3/3	0/0	1/1	1/1	1/1	1/1						
Potassium dichromate	K ₂ Cr ₂ O ₇	007778-50-9	aqueous	T	0/0	0/0	3/0	1/0	3/0	0/0	3/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	2/0	3/3	0/0	1/1	1/1	1/1	1/1						
Potassium ferricyanide	C ₆ FeK ₃ N ₆	013746-66-2	each	Xn	1/1	1/1	1/0	(1)	(1)	0/0	2/0	1/1	1/1	0/0	1/3	1/1	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	1/1	1/1	1/1	1/1						
Potassium ferrocyanide	C ₆ FeK ₄ N ₆ x 3H ₂ O	014459-95-1	saturated	—	1/1	1/1	1/0	(2)	(1)	0/0	2/0	1/1	0/0	0/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	(1)	1/1	1/1							
Potassium ferrocyanide	C ₆ FeK ₄ N ₆ x 3H ₂ O	014459-95-1	diluted	—	1/0	1/1	1/0	(1)	(1)	0/0	2/0	1/1	0/0	0/0	1/3	1/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	(1)	0/0	1/1	1/1	1/1							
Potassium fluoride	KF	007789-23-3	—	T	1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	(1)	(1)	1/0	(1)	0/0	1/1	1/1	1/1	0/0						
Potassium hydrogen carbonate	CHKO ₃	000298-14-6	saturated	—	1/1	1/1	1/0	(2)	(2)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	0/0	4/4	(1)	(1)	1/1						
Potassium hydroxide	KHO	001310-58-3	10 %	C+	1/1	1/1	1/0	4/4	4/4	0/0	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/0	4/4	3/3	0/0	4/4	1/1	1/1	1/1		Caustic potash; Potassium hydrate; Potassium lye				
Potassium hydroxide	KHO	001310-58-3	30 %	C+	1/1	1/1	1/3	4/4	4/4	1/0	(3)	1/1	1/0	1/0	1/3	1/0	0/0	0/0	0/1	(2)	1/0	4/4	3/3	0/0	4/4	1/1	1/1	1/1							
Potassium hydroxide	KHO																																		

CHEMICALS	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	thermoplastics										fluoroplastics		elastomers		metals				COMMENT								
					FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE /ETFE	FEP	PTFE	PVDF		EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C
Propanone, 2-	-> see: Acetone																														
Propargyl alcohol	C ₃ H ₄ O	000107-19-7	7 %	Xn		1/1	1/1	(3)	1/0	0/0	0/0	(2)	1/1	0/0	0/0	1/1	1/0	0/0	0/0	(1)	1/1	1/3	1/0	1/1	1/1	0/0	1/0	(1)	(1)	0/0	
Propenenitrile, 2-	-> see: Acrylonitrile																														
Propenyl alcohol	-> see: Allyl alcohol																														
Propionic acid	C ₃ H ₆ O ₂	000079-09-4	50 %	C		1/3	1/3	3/3	4/4	0/0	0/0	4/4	1/1	4/4	4/4	1/3	3/3	0/0	0/0	(1)	1/1	1/1	3/0	1/1	4/4	0/0	1/1	(1)	(1)	1/1	
Propionic acid	C ₃ H ₆ O ₂	000107-09-4		C		1/3	1/3	3/3	4/4	0/0	0/0	4/4	1/3	4/4	4/4	4/4	0/0	0/0	1/0	1/1	1/1	4/4	3/0	4/4	0/0	1/1	1/2	1/1	1/1		
Propyl acetate, normal	C ₆ H ₁₀ O ₂	000109-60-4		F	X	0/0	0/0	(1)	4/4	0/0	(4)	1/0	(2)	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	3/0	4/4	4/4	0/0	(1)	(1)	(1)			
Propyl alcohol	C ₃ H ₈ O	000071-23-8		F	X	1/1	1/1	1/1	1/0	1/0	0/0	1/1	1/1	3/0	0/0	2/2	3/3	1/4	0/0	1/1	1/1	1/1	1/0	1/1	3/3	0/0	1/1	(1)	(1)	0/0	
Propyl carbinol	-> see: Butyl alcohol, normal																														
Propyl nitrate	C ₃ H ₇ NO ₃	000627-13-4		(E, Xn)	(X)	0/0	0/0	(3)	(3)	0/0	0/0	(3)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	3/0	4/4	4/4	0/0	(2)	(1)	(1)		
Propylamine, n-	C ₃ H ₇ N	000107-10-8		F, C, Xn	X	0/0	0/0	0/0	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	4/4	4/4	0/0	(1)	(1)	(1)		
Propylene	C ₃ H ₆	000115-07-1		F+	X	1/1	1/1	1/0	(3)	1/0	0/0	1/0	1/1	4/4	0/0	3/4	4/4	0/0	0/0	(1)	1/1	(1)	4/4	1/0	4/4	0/0	1/1	1/1	1/1		
Propylene glycol	C ₃ H ₈ O ₂	000057-55-6		—		1/1	1/1	4/4	2/3	(2)	1/1	1/0	1/1	1/1	2/2	3/4	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/3	0/0	1/1	(1)	(1)	1/1		
Propylene oxid	C ₃ H ₆ O	000075-56-9		F+, T	X	1/1	1/2	(3)	2/3	0/0	1/2	(2)	1/2	4/4	2/2	3/4	0/0	4/4	3/4	1/1	1/0	1/4	3/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0	Epoxypropane, 1,2-; Methyloxirane; Methyl ethylene oxide
Pydraul C (312, 540)	—	—		(Xn)		0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	4/4	1/0	4/4	0/0	0/0	(1)	(1)			based on phosphoric ester; Monsanto
Pydraul E (29, 30, 50, 65, 90, 11)	—	—		(Xn)		0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	0/0	1/0	1/0	4/4	0/0	0/0	(1)	(1)			based on phosphoric ester; Monsanto
Pyridine	C ₅ H ₅ N	000110-86-1		F, Xn	X	1/3	0/2	1/0	4/4	0/0	0/2	1/1	3/3	4/4	4/4	4/4	4/4	1/1	(2)	1/1	1/3	4/4	4/4	4/4	0/0	1/1	1/1	1/1	0/0		Azine; Azabenzene
Pyrogallol acid	C ₆ H ₆ O ₃	000087-66-1		Xn		0/0	0/0	1/0	(3)	0/0	0/0	3/4	1/0	3/0	0/0	0/0	0/0	1/3	0/0	(1)	(1)	1/1	(3)	(3)	(3)	0/0	1/1	1/1	1/1	1/1	
Pyroligneous oil	—	008001-20-5		—		0/0	0/0	(1)	(2)	1/0	0/0	(1)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	4/4	(1)	1/0	0/0	1/1	(1)	(1)		
Pyrrrole	C ₄ H ₅ N	000109-97-7		Xn	X	0/0	0/0	(3)	(4)	0/0	0/0	(2)	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	4/4	4/4	0/0	(1)	(1)	(1)		Azole; Imidole
Quinine	C ₂₀ H ₂₄ N ₂ O ₂	000130-95-0		Xn		1/1	1/1	(2)	(2)	(2)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(2)	(2)	(1)	0/0	(2)	(1)	(1)	0/0	
Quinol	-> see: Hydroquinone																														
Ramasit	—	—		?		0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	(1)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	0/0	for moisture-proofing of textiles; BASF
Resorcinol	C ₆ H ₆ O ₂	000108-46-3	5 %	—		1/1	1/1	4/4	2/3	0/0	1/1	(3)	1/1	2/3	4/4	2/4	0/0	3/3	1/3	1/1	(1)	(3)	(3)	(3)	(3)	0/0	(2)	0/0	0/0	0/0	
Resorcinol	C ₆ H ₆ O ₂	000108-46-3	saturated	Xn		1/1	1/1	4/4	2/3	0/0	1/1	(3)	1/1	2/3	4/4	3/4	0/0	0/0	1/1	(1)	(1)	(3)	(3)	(3)	(3)	0/0	(2)	0/0	0/0	0/0	
Roaster off-gas	—	—	each	(T)		0/0	0/0	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	4/4	0/0	(4)	(2)	(2)	0/0	
Rose oil	—	008007-01-0		?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	3/0	0/0	(1)	(1)	(2)	(3)	(3)	(3)	0/0	(1)	(1)	(1)		
Rum ether	—	008030-89-5		?		0/0	0/0	(2)	(3)	0/0	0/0	(2)	(2)	4/4	0/0	0/0	0/0	1/0	0/0	(1)	(1)	(3)	(3)	(4)	(3)	0/0	(1)	(1)	(1)		
Sagrotan	—	—	liquid	?		1/2	1/3	0/0	3/0	0/0	(3)	1/3	3/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	1/0	3/0	0/0	(2)	(1)	(1)		disinfectant; Schülke & Mayr
Salicyl acid	C ₇ H ₆ O ₃	000069-72-7	saturated	(Xn, Xi)		1/1	1/1	1/0	1/2	1/0	1/1	4/4	1/1	1/2	1/1	2/3	0/0	1/1	1/1	1/1	1/0	1/1	1/0	1/0	3/3	0/0	1/0	1/0	1/0	1/1	
Salicyl acid	C ₇ H ₆ O ₃	000069-72-7	powder	Xn, Xi		1/1	1/1	1/0	1/2	(1)	1/2	(3)	1/1	1/1	1/1	2/3	0/0	0/0	1/1	1/1	1/0	1/1	1/0	1/0	3/3	0/0	1/0	1/0	1/0	1/1	
Salicylaldehyde	C ₇ H ₆ O ₂	000090-02-8		Xn, Xi		1/1	1/2	(3)	2/3	0/0	1/2	(3)	1/2	4/4	3/3	3/4	0/0	0/0	1/4	1/1	(1)	(3)	(3)	(3)	4/4	0/0	(2)	(1)	(1)	1/1	
Salt spring	NaCl	007647-14-5	saturated	—		1/1	1/1	1/0	(1)	(1)	0/0	1/2	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/1	1/1	0/0	3/4	1/3	1/2	0/0	
Salt water, sea water	—	—		—		1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/1	1/1	0/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	3/4	1/3L	1/2L	1/1		
Salt peter	-> see: Potassium nitrate																														
Saturated steam condensate	—	—		?		0/0	0/0	(2)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(2)	(2)	(2)	(2)	0/0	(2)	1/1	1/1		
Sea water	—	—		—		1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/1	1/1	0/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	3/4	1/3L	1/2L	1/1	
Silicofluoric acid	H ₂ SiF ₆	016961-83-4	32 %	C		1/1	1/1	4/4	1/0	4/4	0/0	4/4	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	3/0	2/2	3/4	0/0	4/4	(2)	1/1	1/1	
Silicone greases	—	—		(—)		0/0	0/0	1/0	1/0	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(1)	(1)	1/0	1/0	1/1	0/0	1/1	1/1	1/1		
Silicone oil	—	—		?		1/1	1/1	1/0	1/0	1/0	1/1	1/1	3/3	1/0	1/4	0/0	1/1	0/0	1/1	1/1	(1)	1/0	1/1	1/1	0/0	1/1	1/1	1/1	1/1		polysiloxane
Silver acetate	C ₂ H ₃ AgO ₂	000563-63-3		Xi		1/1	1/1	(2)	1/2	(2)	1/1	(2)	1/1	2/2	1/1	2/2	0/0	0/0	1/1	1/1	(1)	(1)	(1)	(2)	(3)	0/0	(4)	0/0	0/0	0/0	
Silver cyanide	AgCN																														

CHEMICALS	thermoplastics																												fluoroplastics				elastomers				metals			
	FORMULA	CAS-NR	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C	COMMENT									
Sodium carbonate	Na ₂ CO ₃	000497-19-8		Xi		1/1	1/1	1/0	1/0	0/0	1/1	1/1	1/1	2/0	0/0	1/1	0/0	1/2	1/1	1/1	1/1	1/3	1/1	1/1	1/1	0/0	3/4	1/1	1/1	1/1										
Sodium chlorate	NaClO ₃	007775-09-9	each	O, Xn		1/1	1/0	1/0	1/0	0/0	1/0	2/0	1/1	1/0	0/0	1/3	0/0	1/0	1/1	1/1	1/1	1/0	1/1	2/3	0/0	1/0	1/1L	1/1L	1/1L	1/1	Chloric acid, sodium salt;									
Sodium chlorate	NaClO ₃	007775-09-9	aqueous	O, Xn		0/0	0/0	3/0	1/0	1/0	0/0	2/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	3/3	0/0	1/0	1/1L	1/1L	1/1L										
Sodium chloride	NaCl	007647-14-5	each	—		1/1	1/1	1/0	1/1	1/1	1/0	1/2	1/1	1/1	1/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	3/4	1/2	1/2	1/1										
Sodium chloride	NaCl	007647-14-5	aqueous	—		1/1	1/1	1/1	1/1	1/1	1/2	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	3/4	1/2	1/2	1/1										
Sodium chlorite	NaClO ₂	007758-19-2	diluted	(O, Xn)		1/0	1/3	1/4	(2)	0/0	0/0	(2)	1/3	0/0	0/0	3/0	4/4	0/0	0/0	(1)	1/1	1/1	1/0	1/1	4/4	0/0	3/4	3/4	3/3	0/0										
Sodium chromate	NaCrO ₄	007775-11-3	diluted	T		1/0	1/0	1/1	(2)	0/0	0/0	(2)	1/1	1/1	0/0	1/3	0/0	1/1	0/0	(1)	1/1	1/1	1/0	1/0	1/3	0/0	1/1	1/1	1/1	0/0										
Sodium cyanide	CNNa	000143-33-9	saturated	T		1/1	1/1	1/0	(3)	0/0	0/0	3/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	3/3	0/0	4/4	(2)	(2)	0/0	Hydrocyanic acid, sodium salt;								
Sodium cyanide	CNNa	000143-33-9	aqueous	T		1/1	1/1	1/0	(3)	1/0	0/0	3/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	4/4	(2)	(2)	0/0										
Sodium dichromate	Na ₂ Cr ₂ O ₇	010588-01-9		T		0/0	1/1	1/0	1/0	3/0	1/1	(3)	1/1	1/1	0/0	1/0	0/0	0/0	1/1	(1)	1/1	1/1	1/0	1/0	3/3	0/0	1/1	(1)	(1)	1/1										
Sodium dithionite	-> see: Sodium hydrosulfite																																							
Sodium dodecylbenzene sulfonate	C ₁₈ H ₂₉ NaSO ₃	025155-30-0		Xn		1/1	1/1	(2)	(2)	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	(1)	(1)	(1)	(2)	0/0	(2)	(1)	(1)											
Sodium ferrocyanide	C ₆ FeNa ₆ N ₆	013601-19-9		Xn		1/1	1/1	(1)	(2)	(1)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(1)	(1)	(1)	(2)	0/0	(1)	(1)												
Sodium fluoride	NaF	007681-49-4	saturated	T		1/1	1/1	1/0	(2)	(1)	1/0	1/1	1/1	1/0	0/0	1/0	1/3	1/1	0/0	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	0/0	0/0	1/1										
Sodium hydrosulfite	Na ₂ S ₂ O ₄	007775-14-6	10 %	Xn		1/1	0/0	(2)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	1/3	0/0	1/1	0/0	(1)	1/1	1/3	1/0	1/1	3/3	0/0	4/4	1/1	1/1		Sodium dithionite; Dithionous acid, disodium salt; Sodium sulfoxylate;									
Sodium hydrosulfite	Na ₂ S ₂ O ₄	007775-14-6		Xn		1/1	0/0	(2)	(2)	0/0	(2)	1/1	0/0	0/0	1/3	0/0	1/1	0/0	(1)	1/1	1/3	1/0	1/1	3/3	0/0	4/4	1/1	1/1												
Sodium hydroxide	NaOH	001310-73-2	concentrated	C		1/1	1/1	1/3	4/4	4/4	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	(2)	1/0	4/4	3/4	0/0	4/4	(2)	(2)	?	caustic soda, sodium hydrate, soda lye									
Sodium hydroxide	NaOH	001310-73-2	30 %	C+		1/1	1/1	1/0	4/4	4/4	1/0	1/3	1/1	1/0	1/0	1/3	1/3	0/0	0/0	1/1	1/1	(2)	1/0	(3)	2/3	0/0	4/4	1/3	1/3	1/1	caustic soda, sodium hydrate, soda lye									
Sodium hydroxide	NaOH	001310-73-2	45 %	C+		1/1	1/1	1/0	4/4	4/4	1/0	1/3	1/1	1/1	1/0	1/3	1/3	1/1	0/0	0/0	1/1	(2)	1/0	2/4	2/3	0/0	4/4	1/3	1/3	1/1	caustic soda, sodium hydrate, soda lye									
Sodium hydroxide	NaOH	001310-73-2	50 %	C+		1/1	1/1	1/0	4/4	4/4	1/1	1/3	1/1	2/2	1/1	1/2	0/0	0/3	1/1	1/1	1/1	3/3	1/0	3/4	3/3	0/0	4/4	1/3	1/3	1/1	caustic soda, sodium hydrate, soda lye									
Sodium hydroxide	NaOH	001310-73-2	60 %	C+		1/1	1/1	1/0	4/4	4/4	1/0	(3)	1/1	1/0	1/0	0/0	0/0	0/0	0/0	0/0	1/1	(2)	1/0	3/4	2/3	0/0	4/4	1/3	1/3	1/1	caustic soda, sodium hydrate, soda lye									
Sodium hydroxide	NaOH	001310-73-2	1 %	Xi		1/1	1/1	1/0	3/4	(3)	1/1	1/1	1/1	2/2	1/1	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/3	0/0	(4)	1/1	1/1	1/1	caustic soda, sodium hydrate, soda lye									
Sodium hypochlorite	NaClO	007681-52-9	diluted	(O, C)		2/3	2/3	4/4	(3)	3/0	1/3	4/4	2/3	1/3	1/1	1/3	1/0	1/1	0/0	1/1	1/1	1/1	3/0	1/3	4/4	0/0	4/4	3/3L	2/2L	0/0	sodium oxychloride, sodium chloride oxide									
Sodium hypochlorite	NaClO	007681-52-9	15 %	O, C		2/3	2/3	4/4	2/3	(3)	1/3	4/4	2/3	1/3	1/1	1/1	0/0	1/1	1/1	1/1	1/1	3/4	3/0	1/3	4/4	0/0	4/4	3/3L	2/2L	0/0	sodium oxychloride, sodium chloride oxide									
Sodium hypochlorite	NaClO	007681-52-9	saturated	O, C		2/3	2/3	4/4	2/3	(3)	1/3	4/4	2/3	1/3	1/1	1/3	0/0	1/1	0/0	(1)	1/1	(3)	3/0	1/3	4/4	0/0	4/4	3/3L	2/2L	0/0	sodium oxychloride, sodium chloride oxide									
Sodium hypochlorite	NaClO	007681-52-9	12,5 % Cl	O, C		2/3	2/3	4/4	2/3	(3)	1/3	4/4	2/3	1/3	1/1	1/3	1/0	1/1	1/1	1/1	1/1	3/0	1/3	4/4	0/0	4/4	3/3L	2/2L	0/0	sodium oxychloride, sodium chloride oxide										
Sodium iodide	NaI	007681-82-5	each	Xi		1/1	1/1	(2)	(1)	(1)	0/0	1/1	1/0	0/0	0/0	1/3	0/0	0/0	1/1	1/1	1/1	1/3	(1)	(1)	1/1	0/0	1/1	3/4	3/4	0/0										
Sodium metabisulfite	Na ₂ S ₂ O ₅	007681-57-4	each	Xn		1/1	1/1	1/0	(2)	(2)	0/0	4/4	1/1	0/0	0/0	1/3	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	1/0	1/0	1/1	1/1	1/1											
Sodium nitrate	NaNO ₃	007631-99-4	saturated	O, Xn		1/1	1/1	1/0	1/0	(1)	1/0	1/1	1/1	1/1	1/0	1/3	1/3	1/1	1/1	1/1	1/1	1/1	1/0	1/1	2/3	0/0	1/1	1/1	1/1	1/1	chile saltpeter									
Sodium nitrate	NaNO ₃	007631-99-4	aqueous	O, Xn		1/1	1/1	1/0	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	chile saltpeter									
Sodium nitrite	NaNO ₂	007632-00-0	saturated	O, T		1/1	1/1	1/0	(2)	(1)	1/0	1/1	1/1	1/1	0/0	1/0	1/0	1/1	0/0	(1)	1/1	1/1	1/0	1/1	2/3	0/0	1/0	1/1	1/1	1/1	Nitrous acid, sodium salt;									
Sodium nitrite	NaNO ₂	007632-00-0	aqueous	O, T		1/1	1/1	1/0	(2)	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/1	1/0	1/0	1/0	1/1	1/1	1/1										
Sodium oxalate	C ₂ Na ₂ O ₄	000062-76-0	saturated	Xn		1/1	1/1	(1)	(1)	(1)	0/0	1/1	1/1	0/0	0/0	1/3	0/0	0/0	1/1	1/1	1/1	1/3	(1)	1/0	1/0	0/0	1/1	(2)	(2)											
Sodium perborate	NaBO ₂ (HO) ₂ x 3H ₂ O	013517-20-9	saturated	(O, Xn)		1/1	1/1	4/4	(2)	0/0	0/0	2/0	1/1	1/1	0/0	1/0	3/0	1/1	0/0	(1)	1/1	1/1	1/0	1/0	3/0	0/0	1/0	1/0	1/0	1/0										
Sodium perborate	NaBO ₂ (HO) ₂ x 3H ₂ O	013517-20-9	aqueous	(O, Xn)		1/1	1/1	4/4	(2)	3/0	0/0	2/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	3/0	0/0	1/0	1/0	1/0	1/0										
Sodium perchlorate	NaClO ₄	007601-89-0	saturated	O, Xn		1/1	1/1	(2)	(1)	(1)	0/0	1/1	1/1	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/1	1/0	1/0	(1)	0/0	1/1	1/1	1/1	1/1										
Sodium peroxide	Na ₂ O ₂	001313-60-6	10 %	O, C+		0/0	1/3	4/4	(3)	(4)	0/0	4/4	2/2	0/0	0/0	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/0	1/0	3/0	0/0	4/4	1/1	1/1	0/0										
Sodium peroxide	Na ₂ O ₂	001313-60-6	saturated	O, C+		0/0	3/3	4/4	(3)	(4)	0/0	4/4	2/2																											

CHEMICALS	thermoplastics																												fluoroplastics		elastomers		metals			
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE /ETFE	FEP	PTE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C	COMMENT					
Spindle oil	—	—	—	?	—	3/3	2/3	(2)	(2)	1/0	0/0	(2)	1/4	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	(4)	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/1					
Spinning bath acid	—	—	100mg CS ₂ /l	?	—	1/0	0/0	4/4	(3)	0/0	0/0	4/4	1/0	0/0	0/0	1/0	0/0	0/0	0/0	(1)	1/1	1/0	(3)	(2)	4/4	0/0	(4)	3/4	2/4	0/0						
Spirit (of wine)	C ₂ H ₆ O	—	—	F	X	1/0	1/3	1/0	1/3	1/1	1/2	1/2	1/1	3/4	1/2	1/3	3/0	1/3	1/1	1/1	1/1	1/1	1/0	3/0	3/3	0/0	1/1	1/1	1/1	1/1		ethyl alcohol				
Spirits	C ₂ H ₆ O	—	—	—	—	1/1	1/0	1/0	1/1	1/1	0/0	1/2	1/1	0/0	1/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	1/1	1/1	1/1	0/0	ethyl alcohol 40 %				
Spirits of Turpentine	—	008006-64-2	—	Xn	X	2/2	3/4	1/0	4/4	1/0	3/3	1/1	4/4	4/4	4/4	2/3	4/4	3/3	1/1	1/1	1/0	1/3	4/4	1/1	3/3	0/0	1/1	1/1	1/1	1/1	1/1					
Spirits of wine	C ₂ H ₆ O	—	50 %	(F)	X	1/0	1/1	1/0	1/1	1/1	1/0	1/2	1/1	1/0	1/0	1/0	3/0	0/0	0/0	1/1	1/1	1/1	1/0	(2)	1/1	0/0	1/1	1/1	1/1	1/1	1/1	ethyl alcohol				
Spirits of wine	C ₂ H ₆ O	—	96 %	F	X	1/0	1/3	1/0	1/3	1/1	1/2	1/2	1/1	3/4	1/2	1/3	3/0	1/3	1/1	1/1	1/1	1/1	1/0	3/0	3/3	0/0	1/1	1/1	1/1	1/1	1/1	ethyl alcohol				
Spruce oil	—	008008-80-8	—	?	—	1/2	2/4	(2)	2/3	0/0	2/3	(2)	1/2	4/4	3/3	3/4	0/0	3/4	1/2	1/1	(1)	(2)	4/4	1/0	3/3	0/0	(1)	(1)	(1)			pinus sylvestris				
Stannic chloride	SnCl ₄	007646-78-8	aqueous	C	—	1/1	1/1	4/4	(3)	0/0	0/0	(4)	1/1	4/4	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	4/4	4/4	3/4							
Stannous chloride	SnCl ₂	007772-99-8	aqueous	(C, Xn)	—	1/1	1/1	(4)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	4/4	4/4	3/4	1/1						
Stannous chloride	SnCl ₂	007772-99-8	saturated	C, Xn	—	1/1	1/1	4/4	1/0	0/0	0/0	(2)	1/1	1/1	0/0	1/0	1/0	1/1	0/0	1/1	1/1	1/1	1/0	1/1	1/1	0/0	4/4	4/4	3/4	1/1						
Starch solution	(C ₆ H ₁₀ O ₅) _n	—	each	—	—	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1	0/0					
Starch syrup	—	—	—	—	—	1/1	1/1	1/1	1/1	1/0	0/0	1/1	1/1	0/0	0/0	1/1	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0/0	1/1	1/1	1/1	1/1	0/0					
Stauffer grease, thick	—	—	—	(—)	—	0/0	0/0	(2)	(2)	(1)	0/0	(1)	(2)	1/4	0/0	0/0	0/0	1/1	0/0	(1)	1/1	(1)	4/4	(1)	(2)	0/0	(1)	1/1	1/1	0/0						
Steam	H ₂ O	—	up to 150°C	?	—	4	4	4/4	0/0	0	0	(3)	(3)	0	0	0	0	0	0	0	0	1	0	1	3	4/4	0	(1)	1/1	1/1						
Stearic acid	C ₁₈ H ₃₆ O ₂	000057-11-4	crystals	Xi	—	1/3	1/3	1/0	1/2	1/0	1/1	1/0	1/3	1/2	2/2	1/2	1/1	1/1	1/1	1/1	1/1	1/1	3/0	1/1	3/3	0/0	1/1	1/1	1/1	1/1						
Strontium bromide	SrBr ₂	010476-81-0	—	Xi	—	1/1	1/1	(2)	(1)	(1)	0/0	(1)	1/1	0/0	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	(1)	(1)	(2)	0/0	(3)	0/0	0/0							
Strychnine	C ₂₁ H ₂₂ N ₂ O ₂	000057-24-9	—	T+	—	1/1	1/1	(1)	(1)	(1)	0/0	(2)	(1)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(2)	(2)	(2)	0/0	(2)	(1)	(1)							
Styrene	C ₈ H ₈	000100-42-5	100 %	Xn, Xi	X	4/4	3/4	1/1	4/4	1/1	(4)	1/1	3/4	0/0	0/0	4/4	4/4	0/0	0/0	1/0	1/1	(2)	4/4	3/0	4/4	0/0	1/1	1/1	1/1	0/0						
Succinic acid	C ₄ H ₆ O ₄	000110-15-6	50 %	Xi	—	1/1	1/1	(3)	(2)	0/0	0/0	(3)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	(1)	0/0	1/1	1/0	1/0	1/1						
Succinic acid	C ₄ H ₆ O ₄	000110-15-6	saturated	Xi	—	1/1	1/1	(3)	(2)	0/0	0/0	(3)	1/1	1/1	0/0	1/3	1/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/0	1/0	?						
Sugar acid	—	—	saturated	(Xi)	—	1/1	1/1	(3)	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	(1)	(1)	0/0	(3)	0/0	0/0								
Sugar beet juice	—	—	—	—	—	1/1	1/1	1/0	1/0	0/0	1/0	1/1	1/1	1/0	0/0	1/0	1/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	(2)	(1)	(1)							
Sugar syrup	—	—	—	—	—	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/3	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1						
Sulfur	S ₈	007704-34-9	techn. pure	Xi	—	1/1	1/1	1/0	1/0	(2)	0/0	1/0	1/1	1/1	0/0	3/0	3/4	1/1	0/0	(1)	1/1	1/1	3/0	1/1	4/4	0/0	(1)	1/1	1/1	1/1	1/1	flower of sulfur				
Sulfur (mono)chloride	S ₂ Cl ₂	010025-67-9	—	C	—	0/0	0/0	4/4	(3)	0/0	0/0	4/4	4/4	0/0	0/0	0/0	0/0	0/0	0/0	1/0	1/1	1/0	4/4	1/0	4/4	0/0	3/4	1/1	1/1	1/1	0/0					
Sulfur dioxide	SO ₂	007446-09-5	damp	T, C	—	1/1	1/1	(3)	(3)	0/0	1/1	4/4	1/3	3/4	2/2	1/2	0/0	0/0	1/1	1/1	1/1	1/4	1/0	4/4	4/4	0/0	3/4	1/1	1/1	1/0		with H2O->sulfurous acid				
Sulfur dioxide	SO ₂	007446-09-5	liquid	T, C	—	3/4	4/4	(3)	3/4	0/0	4/4	4/4	4/4	4/4	2/2	3/4	0/0	0/0	1/2	1/1	1/1	4/4	1/0	4/4	4/4	0/0	(3)	(1)	(1)	1/0		with H2O->sulfurous acid				
Sulfur hexafluoride	SF ₆	002551-62-4	—	—	—	0/0	0/0	1/0	(2)	1/0	0/0	1/0	(2)	0/0	0/0	0/0	0/0	1/0	0/0	(1)	(2)	1/0	3/0	1/0	0/0	(1)	(1)	(1)								
Sulfur trioxide	SO ₃	007446-11-9	C+	—	—	4/4	4/4	4/4	(4)	(4)	0/0	4/4	4/4	0/0	0/0	4/4	0/0	0/0	0/0	(2)	(2)	3/4	3/0	1/0	4/4	0/0	(3)	(1)	(1)	0/0						
Sulfur, melted, 121 °C	S ₈	007704-34-9	?	?	—	0	0	(4)	(3)	0	4	4	4	4	0	0	0	0	0	0	(1)	0	4	1	4	0	(3)	1	1	0/0						
Sulfuric acid	H ₂ SO ₄	007664-93-9	40 %	C+	—	1/1	1/1	4/4	2/0	(4)	1/2	4/4	1/1	2/0	3/0	1/3	1/3	1/1	1/1	1/1	1/1	(3)	1/1	4/4	0/0	3/4	2/3	2/3	0/0							
Sulfuric acid	H ₂ SO ₄	007664-93-9	60 %	C+	—	1/3	1/3	4/4	3/3	(4)	1/2	4/4	1/3	2/4	1/1	1/2	0/0	0/0	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	4/4	4/4	3/4	0/0						
Sulfuric acid	H ₂ SO ₄	007664-93-9	80 %	C+	—	1/1	1/1	4/4	3/4	4/4	1/2	4/4	1/1	3/4	3/0	1/1	1/3	0/0	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	4/4	2/4	2/3	0/0						
Sulfuric acid	H ₂ SO ₄	007664-93-9	95 %	C+	—	3/4	3/4	4/4	4/4	4/4	2/2	4/4	3/4	4/4	4/4	2/4	0/0	4/4	1/1	1/1	1/1	1/1	4/4	1/1	4/4	0/0	4/4	1/3	1/3	0/0						
Sulfuric acid	H ₂ SO ₄	007664-93-9	fuming	C+	—	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/0	0/0	(1)	1/0	4/4	4/4	1/0	4/4	0/0	(3)	1/2	1/1	0/0		oleum				
Sulfuric acid	H ₂ SO ₄	007664-93-9	1-6 %	Xi	—	1/1	1/1	4/4	1/1	0/0	1/1	4/4	1/1	1/2	1/1	1/2	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	3/0	0/0	(3)	2/2	1/2	0/0						
Sulfuric acid	H ₂ SO ₄	007664-93-9	20 %	Xi																																

CHEMICALS	thermoplastics																												fluoroplastics		elastomers		metals		COMMENT
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C					
Titanium (tetra)chloride	TiCl ₄	007550-45-0		C		0/0	0/0	4/4	(3)	0/0	0/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(3)	4/4	(3)	4/4	0/0	(4)	0/0	0/0						
Toluene	—	092045-38-0	100 %	T		1/0	1/3	1/0	(3)	0/0	0/0	1/0	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	3/0	4/4	0/0	(1)	1/1	1/1						
Train oil	—	—		—		0/0	0/0	1/0	(2)	1/0	0/0	(1)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(1)	3/4	1/0	1/0	0/0	(1)	(1)	(1)						
Transformer oil	—	—		?		1/3	3/3	1/0	(3)	1/1	1/0	3/3	1/3	1/3	1/0	1/0	0/0	1/3	0/0	(1)	1/1	(3)	4/4	2/3	3/3	0/0	1/1	(1)	(1)	0/0					
Triacetin	C ₉ H ₁₄ O ₆	000102-76-1		Xn		0/0	0/0	0/0	(3)	0/0	0/0	(2)	(2)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	1/0	4/4	3/3	0/0	(1)	(1)	(1)						
Tribromomethane	CHBr ₃	000075-25-2		T		4/4	4/4	4/4	4/4	4/4	4/4	(4)	4/4	4/4	4/4	4/4	0/0	2/3	1/1	(1)	(2)	4/4	(4)	4/4	0/0	(3)	0/0	0/0	0/0						
Tributyl citrate (TBC)	C ₁₈ H ₃₂ O ₇	000077-94-1		—		1/2	2/3	(2)	4/4	0/0	2/3	(2)	2/3	4/4	3/3	3/4	0/0	0/0	1/2	1/1	(1)	(2)	(3)	(3)	(3)	0/0	(1)	(1)	(1)						
Tributyl phosphate (TBP)	C ₁₂ H ₂₇ PO ₄	000126-73-8	techn. pure	Xn		1/1	1/1	1/0	(3)	0/0	0/0	(2)	1/3	0/0	0/0	4/4	4/4	0/0	0/0	(1)	1/1	1/0	3/0	4/4	4/4	0/0	(1)	(1)	(1)	1/1					
Trichloroacetaldehyde	C ₂ HCl ₃ O	000075-87-6	100 %	T/Xi		1/1	1/1	4/4	(3)	(4)	0/0	(3)	1/1	0/0	0/0	4/4	4/4	0/0	0/0	(1)	0/0	(4)	3/0	(4)	4/4	0/0	4/4	0/0	0/0	0/0					
Trichloroacetic acid (TCA)	C ₂ HCl ₃ O ₂	000076-03-9		C+		1/4	3/4	4/4	4/4	4/4	0/0	4/4	1/1	4/4	0/0	4/4	4/4	0/0	0/0	1/0	1/1	1/4	3/0	4/4	4/4	0/0	1/3	3/0L	2/0L	1/1					
Trichlorobenzene	C ₆ H ₃ Cl ₃	—	100 %	(Xn)		4/4	4/4	(3)	(3)	0/0	(4)	(2)	4/4	4/4	0/0	4/4	4/4	4/4	0/0	(1)	(2)	(3)	(4)	(3)	4/4	0/0	(2)	0/0	0/0	0/0	isomer not indicated in the source				
Trichloroethane	C ₂ H ₃ Cl ₃	—		Xn		3/4	4/4	3/0	4/4	4/4	4/4	(2)	4/4	4/4	4/4	4/4	4/4	1/2	1/1	(1)	1/3	4/4	1/0	4/4	0/0	4/4	0/0	0/0	0/0	isomer not indicated in the source					
Trichloroethylene (TRI)	C ₂ HCl ₃	000079-01-6	100 %	Xn		3/4	4/4	3/0	4/4	4/4	4/4	4/4	4/4	4/4	4/4	0/4	1/2	1/1	1/0	1/1	4/4	1/3	4/4	0/0	1/3	1/1L	1/1L	1/0							
Trichlorofluoromethane	CCl ₃ F	000075-69-4		N		0/0	0/0	1/0	(3)	0/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(3)	(1)	0/0	4/4	2/0	1/0	0/0	(3)	0/0	0/0	0/0					
Trichlorophenol	C ₆ H ₂ Cl ₃ O	—		(Xn, Xi)		0/0	0/0	(3)	(4)	0/0	0/0	(3)	(3)	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	(4)	(3)	(4)	0/0	(3)	0/0	0/0			isomer not indicated in the source				
Trichlorotrifluoroethane	C ₂ Cl ₃ F ₃	000076-13-1		?		0/0	0/0	1/0	(3)	1/0	0/0	1/0	(3)	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/0	4/4	3/0	1/0	0/0	(3)	0/0	0/0							
Trichlorotrifluoroethane	C ₂ Cl ₃ F ₃	—	100 %	?		4/4	3/4	1/0	3/0	0/0	0/0	1/0	4/4	4/4	1/0	3/4	4/4	3/3	0/0	0/0	(1)	1/0	4/4	3/0	1/0	0/0	(3)	0/0	0/0		isomer not indicated in the source				
Tricresyl phosphate (TCF)	C ₂₁ H ₂₇ PO ₄	—	techn. pure	T/Xn, N		1/1	1/1	1/0	4/4	1/0	0/0	1/0	1/3	4/4	0/0	4/4	4/4	4/4	0/0	(1)	1/1	(3)	3/0	3/4	4/4	0/0	1/1	1/1	1/1	1/1	isomer not indicated in the source				
Triethanolamine (TEA)	C ₆ H ₁₅ NO ₃	000102-71-6	techn. pure	Xi		1/1	1/2	(2)	(2)	1/0	0/0	2/2	1/1	1/1	0/0	3/0	4/4	1/1	0/0	1/1	1/0	1/0	2/0	4/4	4/4	0/0	(1)	(1)	(1)	0/0					
Triethylamine (TEA)	C ₆ H ₁₅ N	000121-44-8	techn. pure	F, C, Xn	X	0/0	0/0	(2)	(3)	0/0	0/0	1/1	4/4	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	3/4	4/4	3/0	3/4	0/0	(1)	(1)	(1)	0/0					
Triethylene glycol	C ₆ H ₁₄ O ₄	000112-27-6		Xi		1/1	1/1	(3)	1/2	0/0	1/1	1/0	1/1	1/2	1/1	2/3	0/0	1/1	1/1	1/1	(1)	(2)	(2)	(1)	(3)	0/0	(1)	(1)	(1)	0/0					
Triethylene glycol diacetate	C ₁₂ H ₁₈ O ₆	000111-21-7		?		0/0	0/0	(3)	(3)	0/0	0/0	1/0	(2)	0/0	0/0	0/0	0/0	4/4	0/0	(1)	(1)	(3)	(3)	(4)	(4)	0/0	(1)	(1)	(1)						
Trihydroxypropane, 1,2,3-	-> see: Glycerol																																		
Triiodomethane	-> see: Iodoform																																		
Triisopropylbenzene	C ₁₅ H ₂₄	000717-74-8		—		0/0	0/0	(2)	(3)	0/0	(4)	(2)	(3)	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	1/0	1/0	0/0	1/1	(1)	(1)						
Trimethylbenzene, 1,2,4-	C ₉ H ₁₂	000095-63-6		Xn	X	0/0	0/0	(1)	(4)	0/0	0/0	(2)	3/3	4/4	0/0	0/0	0/0	0/0	0/0	(1)	(1)	(2)	4/4	(2)	4/4	0/0	1/1	1/1	1/1	0/0					
Trimethylolpropane	C ₆ H ₁₄ O ₃	000077-99-6	aqueous	—		0/0	0/0	(2)	(2)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	(1)	(2)	(2)	0/0	(1)	(1)	(1)							
Trimethylpentane, 2,2,4-	C ₈ H ₁₈	000540-84-1	techn. pure	F, Xn	X	1/3	1/3	1/0	(2)	1/0	(4)	1/0	1/3	3/4	1/0	1/0	4/4	1/1	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1	0/0	Iso-octane; Isobutyltrimethylmethane				
Trioctyl phosphate	C ₂₄ H ₅₂ PO ₄	000078-42-2	techn. pure	(Xn)		3/0	1/0	1/0	(3)	0/0	0/0	(2)	1/3	0/0	0/0	4/4	0/0	0/0	0/0	(1)	1/1	(3)	3/0	3/4	4/4	0/0	(1)	(1)	(1)	0/0	Tris(2-ethylhexyl) phosphate				
Tripropylene glycol (TPG)	C ₈ H ₁₈ O ₄	024800-44-0		(—)		1/1	1/1	(3)	1/2	0/0	1/1	1/0	1/1	1/1	1/1	2/3	0/0	0/0	1/1	1/1	1/1	(2)	(3)	(2)	(3)	0/0	(1)	(1)	(1)						
Trisodium phosphate	Na ₃ PO ₄	007601-54-9		Xi		1/1	1/1	1/0	(2)	0/0	1/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	(4)	1/1	1/1						
Turbine oil (based on mineral oil)	—	—		?		0/0	0/0	(1)	(2)	1/0	0/0	(2)	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	(2)	1/0	0/0	1/1	1/1	1/1						
Turpentine surrogate	—	—		Xn, N	X	0/0	0/0	1/0	(3)	1/0	(4)	1/0	(3)	4/4	0/0	0/0	0/0	1/3	0/0	(1)	1/1	(1)	4/4	1/1	(3)	0/0	1/1	1/1	1/1	1/1					
Two-stroke oil	—	—	100 %	—		0/0	1/3	1/0	(2)	1/0	0/0	1/1	1/3	0/0	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	4/4	1/0	1/0	0/0	1/1	1/1	1/1						
Undecanol	C ₁₁ H ₂₄ O	000112-42-5		Xi		1/2	1/3	(1)	2/3	(1)	1/2	1/0	1/2	2/2	3/3	1/3	0/0	1/1	1/2	1/1	1/1	(1)	(3)	(1)	(2)	0/0	(1)	(1)	(1)						
Urea	CH ₄ N ₂ O	000057-13-6	aqueous	Xi		1/1	1/1	1/0	1/1	1/0	0/0	1/1	1/1	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/0	1/0	1/1					
Urea	CH ₄ N ₂ O	000057-13-6		Xi		1/1	1/1	1/0	1/1	1/0	1/2	1/1	1/1	1/2	3/3	2/4	3/3	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	1/1	1/0	1/0	1/1					
Uric acid	C ₅ H ₄ N ₄ O ₃	000069-93-2		Xi		1/1	1/1	(2)	1/0	1/0	0/0	1/0	1/0	0/0	0/0	1/0	1/0	0/0	1/1	1/1	1/1	1/0	(1)	(1)	0/0	4/4	1/1	1/1	0/0						
Urine	—	—		—		1/1	1/1	1/0	1/0	1/0	0/0	1/1	1/1	3/0	0/0	1/3	1/0	0/0	1/1	1/1	1/1	1/1	1/0												

CHEMICALS	thermoplastics																														fluoroplastics				elastomers				metals			
	FORMULA	CAS-NR.	CONCENTRATION	HAZARD NOTE	FLAMMABLE	HDPE	LDPE	PA	PC	PETG	PMP	POM	PP	PS	PSU	PVC HART	PVC WEICH	SAN	ECTFE / ETFE	FEP	PTFE	PVDF	EPDM	FPM / FKM	NBR	SI	AL	V2A	V4A	Hastelloy C	COMMENT											
Wines	—	—	—	—	—	1/1	1/1	1/0	1/0	1/1	1/0	(2)	1/1	1/1	1/1	0/0	0/0	0/0	1/1	1/1	1/1	1/0	1/0	1/0	0/0	(4)	1/1	1/1	1/1													
Wort for fermentation	—	—	—	?	—	1/1	1/1	(2)	(2)	(1)	0/0	1/1	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	(2)	(1)	1/0	4/4	0/0	(2)	(1)	(1)	0/0												
Xenon	Xe	007440-63-3	—	—	—	0/0	0/0	1/0	(1)	1/1	0/0	1/1	(2)	0/0	0/0	0/0	0/0	0/0	(1)	1/1	1/1	1/1	1/0	1/0	0/0	1/1	1/1	1/1	1/1													
Xylene	C ₈ H ₁₀	001330-20-7	—	(F), Xn	X	3/4	3/4	1/0	4/4	0/0	3/4	1/2	4/4	4/4	4/4	4/4	4/4	1/2	1/1	1/0	1/3	4/4	1/3	4/4	0/0	1/1	1/1	1/1	1/1	1/1												
Yeast	—	—	each	—	—	1/1	1/1	1/0	(1)	1/0	0/0	1/1	1/1	0/0	0/0	1/0	1/0	0/0	1/1	1/1	1/1	1/1	1/0	1/0	1/1	0/0	1/1	(1)	(1)													
Zinc acetate	C ₄ H ₇ ZnO ₄	000557-34-6	aqueous	Xn, Xi	—	1/1	1/1	(2)	(2)	(2)	0/0	(2)	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	(1)	1/0	(3)	3/3	0/0	(3)	(1)	(1)														
Zinc bromide	ZnBr ₂	007699-45-8	—	C, Xn	—	1/1	1/1	4/4	(2)	0/0	0/0	(2)	1/1	0/0	0/0	0/0	0/0	1/1	0/0	1/1	1/1	(1)	(2)	(1)	(2)	0/0	(3)	0/0	0/0													
Zinc carbonate	ZnCO ₃	003486-35-9	saturated	?	—	1/1	1/1	(1)	1/1	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(2)	(1)	(1)	0/0	small solubility - no chemical effect expected												
Zinc chloride	ZnCl ₂	007646-85-7	aqueous	(C, Xn)	—	1/1	1/1	3/4	(2)	0/0	0/0	2/0	1/1	0/0	0/0	0/0	0/0	0/0	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	3/4	1/4L	1/3L	1/1												
Zinc nitrate	Zn(NO ₃) ₂	007779-88-6	—	O, C, Xn	—	1/1	1/1	1/4	(2)	0/0	0/0	(2)	1/1	1/0	1/0	1/0	1/0	1/1	0/0	1/1	1/1	(1)	1/0	(1)	(2)	0/0	(3)	(1)	(1)	0/0												
Zinc oxide	ZnO	001314-13-2	solid	Xn, Xi	—	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(2)	1/1	1/1		small solubility - no chemical effect expected											
Zinc oxide ointment	—	—	?	?	—	0/0	0/0	(1)	(2)	(2)	0/0	(2)	(2)	1/1	0/0	0/0	0/0	1/1	0/0	(1)	1/1	(2)	(4)	(2)	(2)	0/0	(2)	(1)	(1)													
Zinc phosphate	Zn ₃ (PO ₄) ₂	007779-90-0	saturated	?	—	1/1	1/1	(1)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	(2)	(1)	(1)	0/0												
Zinc sludge	—	—	?	?	—	0/0	0/0	0/0	0/0	0/0	0/0	0/0	1/1	0/0	0/0	0/0	0/0	0/0	0/0	(1)	(2)	0/0	0/0	0/0	0/0	(3)	0/0	0/0														
Zinc stearate	C ₃₆ H ₇₀ ZnO ₄	000557-05-1	—	Xi	—	1/1	1/1	(1)	1/1	0/0	1/1	1/1	1/1	1/1	1/1	1/2	1/1	1/1	1/1	1/1	1/1	(2)	1/1	(2)	0/0	(2)	(1)	(1)														
Zinc sulfate	ZnSO ₄	007733-02-0	10 %	—	—	1/1	1/1	(3)	1/0	(2)	1/0	2/0	1/1	1/1	0/0	1/1	1/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/0	0/0	3/4	1/1	1/1	1/1												
Zinkchlorid	ZnCl ₂	007646-85-7	10 %	C, Xn	—	1/1	1/1	3/4	1/0	0/0	1/1	2/0	1/1	1/3	0/0	1/3	1/0	1/1	1/1	1/1	1/1	1/1	1/0	1/1	1/1	0/0	3/4	1/4L	1/3L	1/1												

Kendrion Kuhnke Automation GmbH
Lütjenburger Straße 101
23714 Malente
Germany
Phone: +49 4523 402-0
Fax: +49 4523 402-201
sales-ics@kendrion.com
www.kuhnke.kendrion.com